



TANNOY®

user manual

QF lex



IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles and the point where they exit from the apparatus.
11. Only use attachments / accessories specified by the manufacturer.
12. Use only with the cart, tripod, bracket or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart / apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Service is required when the apparatus has been damaged in any way, such as power-supply cord or plug damaged, liquid has been spilled or objects have fallen into the apparatus, this apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

SAFETY WARNING

Permanent disconnection from the mains supply is to be achieved by removing the supplied cord connector from the back of the unit.

SAFETY WARNING

Do not remove any covers, loosen any fixings or allow items to enter any aperture.

SAFETY WARNING

Objects filled with liquids should not be placed on this apparatus.

AVERTISSEMENT DE SECURITE

Pour déconnecter l'appareil de l'alimentation principale de façon permanente, débranchez le connecteur du câble fourni à l'arrière de l'appareil.

AVERTISSEMENT DE SECURITE

Ne retirez pas les couvercles, ne desserrez pas les fixations et ne laissez aucune pièce s'introduire dans les ouvertures.

AVERTISSEMENT DE SECURITE

Ne placez pas d'objets contenant du liquide à proximité de l'appareil.

INSTALLATION INSTRUCTIONS

THIS PRODUCT MUST BE EARTHED. Use only a flexible cable or cord provided with a green or green and yellow core which must be connected to the protective earthing terminal of the detachable 'ST18' 16Amp pluggable connector as supplied with the equipment. The other end of the green or green and yellow conductor must be connected to the earthing pin of a suitable mains plug or the earthing terminal of the installation. The cord must be of maximum length 7.5 meters, rated SJ, SJT, or SJE, 10A minimum and be marked VW-1.

1. The electrical power connection to this product is only to be made via a detachable 'ST18' 16Amp pluggable connector as supplied with the equipment. Wiring to this connector must only be made by suitably qualified personnel and must comply with all local requirements.
2. Do not install this equipment in an enclosed space. Do not limit free ventilation and movement of air around the back panel. Ensure that there is at least 60mm (2") of space around all sides of the product for ventilation.
3. Only use attachments and accessories approved by or specified by Tannoy.

FOR CUSTOMERS IN EUROPE

This product complies with both the LVD (electrical safety) 73/23/EEC and EMC (electromagnetic compatibility) 89/336/EEC directives issued by the commission of the European community.

Compliance with these directives implies conformity with the following European standards:

EN60065	Product safety
EN55103-1	EMC emissions
EN55103-2	EMC immunity

This product is intended for the following electromagnetic environments: E2; E3 & E4. Environment E1 (domestic) is specifically excluded.

FOR CUSTOMERS IN THE USA & CANADA

This product has been tested for electrical safety and complies with:

UL60065 7th edition
CA /CSA C22.2 No.60065-03

EMC

This equipment has been designed to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

Industry Canada Class A emission compliance statement: This Class B digital apparatus complies with Canadian ICES-003.

Avis de conformité à la réglementation d'Industrie Canada. Cet appareil numérique de classe A est conforme à la norme ICES-003.

CONTENTS

1 INTRODUCTION

2 UNPACKING

3 SOFTWARE INSTALLATION & SETUP

- 3.1 BeamEngine Programme
- 3.2 MatLab Runtime Library MCR
- 3.3 QFlex BeamEngine Application
- 3.4 Updates
- 3.5 Uninstalling

4 INSTALLING THE MATLAB RUNTIME LIBRARY

5 INSTALLING THE BEAMENGINE APPLICATION

6 USING BEAMENGINE

- 6.1 Menu
- 6.2 Laying Out Venue Planes
- 6.3 Optimize
- 6.4 Adding Additional Venue Items
- 6.5 Probes
- 6.6 Saving Steering File
- 6.7 Balloon Data
- 6.8 BeamEngine – Frequently asked Questions
- 6.9 Some Design Tips

7 INSTALLING VNET SOFTWARE (PODWARE)

8 USING VNET SOFTWARE

- 8.1 Overview
- 8.2 Layout
- 8.3 Menus
- 8.4 Toolbar
- 8.5 Communications
- 8.6 Launching a Panel
- 8.7 Controlling Devices – a quick overview
- 8.8 Parameter Synchronisation
- 8.9 Progress Bar
- 8.8 Navigation
- 8.9 The Selected Device
- 8.10 Device Context Menu
- 8.11 Control Panels
- 8.12 Loading Steering Data
- 8.13 Monicons
- 8.14 Controls
- 8.15 Filter Response Panels
- 8.16 Off-Line Operation
- 8.17 Saving and Recalling Data
- 8.18 Loading Factory Settings
- 8.19 Cloning a Device
- 8.20 Operating Mode
- 8.21 Device Properties
- 8.22 Device Firmware
- 8.23 Keyboard shortcuts

- 9 HARDWARE CONFIGURATION**
- 10 ASSEMBLY INSTRUCTIONS**
 - 10.1 QFlex 8 & QFlex 16 Assembly
 - 10.2 Wall Bracket Mounting Centres
 - QFlex 8 & QFlex 16
 - 10.3 QFlex 24 & QFlex 32 Assembly
 - 10.4 Wall Bracket Mounting Centres
 - QFlex 24 & QFlex 32
 - 10.5 QFlex 40 Assembly
 - 10.6 Wall Bracket Mounting Centres
 - QFlex 40
 - 10.7 QFlex 48 Assembly
 - 10.8 Wall Bracket Mounting Centres
 - QFlex 48
- 11 SYSTEM CONNECTIVITY**
- 12 AUDIO CONNECTIONS**
- 13 NETWORK CONNECTIONS**
- 14 POWER**
- 15 CABLE MANAGEMENT**
- 16 CONTROL INPUTS (SYSTEM INTEGRITY & EMERGENCY PROVISION)**
- 17 INDICATORS**
- 18 SERVICE PARTS**
- 19 TECHNICAL SPECIFICATIONS**
- 20 WARRANTY**

1 INTRODUCTION

Congratulations on the purchase of your new QFlex loudspeaker.

QFlex is a range of self powered, digitally steerable loudspeaker arrays. With state of the art algorithms and dense physical spacing of transducers, QFlex is the first product of its kind to realize full range beam steering capabilities, producing class leading performance for both vocal and music applications. To avoid shipping very long products, it will be possible to assemble the components of a QFlex column on site.

QFlex products are small format, column-type loudspeaker systems with a user-variable vertical beamwidth pattern. The loudspeakers can be used singly or combined in multiples.

The simple to use BeamEngine software allows accurate adjustment of coverage area from a fixed, vertical mounting location. In addition to excellent vocal performance, the QFlex range fully capable of full-range music applications and can also be used in conjunction with any VNET™ subwoofer. Implementation of the network between nodes is via high quality rugged Neutrik Ethercon connectors, which are compatible with standard RJ45 plugs, and CAT5 cable. Each speaker has a unique address for auto-location on the network. System commissioning and ongoing venue network control, incorporating real time diagnostics of electronics and drive unit, are all managed by the exclusive VNET™ software package.

This manual provides information about the design, configuration, and operation of QFlex products. It is intended to be used in conjunction with the VNET™ & BeamEngine Windows software packages.

Please read this user manual to get the optimum performance from your QFlex loudspeaker system.

2 UNPACKING

Every Tannoy QFlex product is carefully tested and inspected before being packaged and leaving the factory. After unpacking your loudspeaker, please inspect for any exterior physical damage, and save the carton and any relevant packaging materials in case the loudspeaker again requires packing and shipping. In the event that damage has been sustained in transit notify your dealer immediately. Each QFlex carton is marked to show each modules position in the array. A detailed description can be found in the Hardware section of this manual.

3 SOFTWARE INSTALLATION & SETUP

QFlex loudspeakers are digitally controlled. A PC running BeamEngine and Vnet software is needed during installation and the commissioning process.

The BeamEngine programme can be obtained by contacting QFlexinfo@tannoy.com

Vnet software and BeamEngine are powerful applications capable of running many complex windows concurrently. They therefore require a computer with reasonable levels of resources.

For acceptable performance, the computer must have at least:

- PC with >450MHz Pentium processor
- 32-bit Windows tm operating system (2000, XP, Vista)
- 128MB RAM
- 500MB Disk space
- Screen with 1024 x 768 Pixel or better
- CD-ROM drive or Internet access
- RS232 or USB port

However, for large systems, larger RAM will make a difference to speed. QFlex makes use of the MatLab Runtime Library MCR, which needs to be installed on your computer in order to run QFlex.

3.1 BEAMENGINE PROGRAMME

There are two programme modules to install. For both the installation is fully automatic. However, please note the following:-

Initialization time: Due to large data-files the installation may need a considerable time to load. Also, on the very first run of QFlex BeamEngine the MatLab Library needs to initialize, which cause a short delay.

Windows Vista: Do not install QFlex BeamEngine to the standard folder but elsewhere, for instance C:\Tannoy\QFlex\.

Restricted User Rights: If you operate your computer under restricted user rights then it is best to install the MatLab Library first and then to install QFlex BeamEngine. If you currently work with administrator rights on your PC the order of installation does not matter.

MatLab owners: If you have already installed MatLab or a MatLab Runtime Library on your computer, the modules should be of version 7.7. Otherwise install the provided package in parallel.

3.2 MATLAB RUNTIME LIBRARY MCR

The MatLab Runtime Library MCR needs to be installed separately. This MatLab Runtime Library is a special version (v7.7) and is exclusively provided to you by Tannoy.

1. Log in as administrator, start the automatic installer by clicking on the link below and follow instructions.
2. Use the default settings.
3. Install MatLab Runtime Library v7.7

3.3 QFLEX BEAMENGINE APPLICATION

Install the QFlex BeamEngine module after the MatLab Library. The install is automatic. Under Vista it is recommended to install into another directory than the one suggested (say "C:\Tannoy\QFlex\" for example).

1. Log in as administrator, start the automatic installer by clicking on the link below and follow instructions.
2. Install Tannoy QFlex

3.4 UPDATES

Install QFlex in the same location. The MatLab Library will not need to be reinstalled.

3.5 UNINSTALLING


Either go to Start Menu/Settings/Software or to the program-folder of QFlex, there double click unins000.exe

4 INSTALLING THE MATLAB RUNTIME LIBRARY


Having downloaded the software, double click on the MCRIInstaller_v77.exe
The following window will appear –




Click on "Run" to start the installer –




Choose the setup language and click 'Ok' to start the InstallShield wizard



The InstallShield window will appear – Click 'Next'




Enter your credentials and click 'Next'



Approve the suggested file location by clicking on 'Next'



Click on 'Install' to begin the Installation



The installation will begin. Due to the file size this may take some time




Click 'Finish' to complete the installation.
There is no need to start this programme as it resides behind the BeamEngine programme. It will no longer be visible.

5 INSTALLING THE BEAMENGINE APPLICATION

Having downloaded the software, double click on the QFlex_vXXXX.exe
The following window will appear.




The QFlex Setup wizard will start; click 'Next' to continue





Accept the terms of the licence agreement to continue with the installation.
Click 'Next' to continue.



Approve the suggested file location by clicking on 'Next'



If you would like the setup programme to create a desktop icon check the box.
Click 'Next' to continue.



Check 'Launch QFlex' if you wish to begin using the software immediately.
Click 'Finish' to complete the setup.

6.1 MENU (File, Edit, Processing, Options, Help)

File

- From here you can create a new project, open an existing and save a project.
- A BeamEngine project has the file extension (.qfl)
- Save a Beamsteering File (.bef)
- Save a 3D Balloon file (.xhn) for export into acoustical simulation programmes.
- Print a detailed project sheet. This includes Parameters, Project Notes & graphs.
- 'Export' generates a screenshot of your current project (.jpg)

Edit

- From here you select your QFlex Model (Keyboard shortcut – F8)
- Add menu item
- Delete menu item

Processing

- Optimize – Creates Beamsteering algorithm (Keyboard shortcut - CTRL + Enter)
- Update Graphs – Regenerates graphics (Keyboard shortcut – SHIFT, CTRL + Enter)

Options

Preferences

Optimizer Tab



Default Property

- Silent and Don't Care is explained in the menu.


The Master Beta function

Master multiplication factor to apply to regularization factors beta given in global A.wf(woofer) and A.tw(tweeter). Normally Masterbeta = 1, but it can be reduced to 0.1, trading some SPL for sharper directivity at the lower end of each sub-array's (tweeter or woofer) working range. It is recommended to use the default setting except in exceptional circumstances

Fill Holes

With multiple primary venue items (multi-beam problems) performance can be improved by setting Fill Holes =1 (instead of 0). Then the narrow gaps in the target directivity are filled up at low frequencies where they can't be implemented anyway. In some cases this produces better results than asking for the impossible. The results are marginal, so no need to spend too much time here.

Units Tab



Verify that you are using the correct measurement units

Misc Tab



By checking this box a shadow will be cast behind venue planes if they are raised above floor level

Help


Here you will find programme info, including version number and a copy of this user manual in PDF format. The first step is to select your QFlex model, using the BeamEngine software is a simple and effective way of selecting the correct model.

Which QFlex system you specify depends on a number of criteria:-

Distance: Farther areas you wish to reach will require a larger QFlex column. Typically, as a rule of thumb a QFlex16 will be used to distances of 20m(66ft), and a QFlex 48 in excess of 80m(260ft)


Low Frequency Control: The larger the QFlex column, the more effective control at lower frequencies can be achieved. This also goes for effective steering control at lower frequencies. QFlex16 (700Hz) >>>> QFlex48 (200Hz)

SPL Requirements: The larger QFlex arrays will have the ability to produce higher SPL levels.



For the purposes of this tutorial we will choose A QFlex 32

6.2 LAYING OUT VENUE PLANES



1. Click on ADD to create a new venue plane(s)
2. Choose SPL to target this particular area from the loudspeaker.

NB. Other Options here are

Silent – This is basically a probe to view the out of beam attenuation on the SPL map.

Don't Care - In the straight forward default case the steering algorithm will aim for silence in all unspecified directions, the user can specify areas where avoiding areas does not matter, for example, areas of high absorption. This may improve results elsewhere, but any differences will be marginal.

3. SPL (x1) is the front, and SPL (x2) is the rear of this specified venue plane. Specify your target/desired SPL here. Specifying these levels has nothing to do with setting absolute volume levels. After optimization you will be notified if there is enough headroom to reach your desired SPL. Manipulating these two levels allows you to adjust the intensity of the sound beam across the specified venue plane. Normally the goal is to achieve an even SPL distribution across the whole venue plane.

Hint: Where even coverage is required over large areas, splitting the venue plane into two sections may yield better results. In this instance you are effectively creating two separate beams which you can manipulate independently, giving you more control. Again, the goal is to achieve an even SPL distribution across the whole venue plane.

4. The first X co-ordinate of the venue plane. (START)
5. The Second X co-ordinate of the venue plane. (END)
6. The First Y co-ordinate of the venue plane. (HEIGHT 1)
7. The Second Y co-ordinate of the venue plane.(HEIGHT 2)
(You may have a sitting or a standing audience. Remember to factor for the listening height when specifying the Y coordinates.)
8. Here you can label your specified venue plane. This is especially helpful if you have multiple target areas.
9. Frequency Band – To view the beam steering characteristic at different frequencies you can view octave bands or the following averages; Broad-Band(125Hz – 8kHz), Low-Band (125Hz - 1kHz), Mid-Band(250Hz - 2kHz), High-Band (1kHz – 8kHz)

Note: Longer arrays will have better low frequency control characteristics

10. Set the height of the loudspeaker. The specified height is to the bottom of the array.


Hint: QFlex will invariably be installed in architecturally sensitive environments. The client or architect will most probably impose restrictions on preferred mounting locations. Beware of mounting the loudspeaker too low. The venue will most probably be empty when you demo or commission the project. If you are in a house of worship, remember that people stand up and sit during a service. Make sure that when people stand they are not masking the sound at the back of the room.

11. Inclination – Not all mounting surfaces are plumb and straight. This feature will allow the programme to factor for any inclinations in the mounting surface.

12. The SPL scale can be referenced against the resultant SPL maps.


13. Optimize: Will generate the steering algorithm based on the supplied information.

6.3 OPTIMIZE




- 1. Resultant Beam based on target data.** From here you can save the steering file and upload to the QFlex hardware from the Vnet software.
- 2. SPL distribution over target area.** To further optimize this particular design the SPL intensity towards the back of the room can be increased slightly to give a more even SPL distribution. Splitting the venue plane into two sections may also yield better results. This effectively creates two separate beams which you can manipulate independently, giving you additional control.
- 3. SPL Headroom.** Indication of SPL headroom available in the design. This figure will show red if the specified SPL cannot be achieved.

6.4 ADDING ADDITIONAL VENUE ITEMS




1. Here we have added a second venue plane, in this case a balcony. BeamEngine will automatically target the second venue plane (no need to specify opening angles or steering angles). Note that the intensity of the second beam has been manually increased to match the SPL of the first venue plane. Both beams can be independently manipulated in this way. Additional venue planes can be added as necessary.
2. By specifying a 'Silent' venue plane, in this example placing it on the roof, you can view the amount of 'out of beam attenuation' at any point in the venue. "Reflector" is labeled a surface if it normally points downwards, i.e. it is part of the ceiling. "Cut" is labeled a surface if it is illuminated by the speaker only partly.

6.5 PROBES




1. Click on the small grey box shown. Drag the line on the SPL key to draw the isobar into the display. The isobar corresponds to the position on the SPL graph.
2. Click on the small grey box shown. Here you can drag and drop the crosshairs shown. Their corresponding co-ordinates and SPL are shown directly below the SPL map.
3. Click on the small grey box shown. Drag the blue probe horizontally across the SPL graph. The SPL across each venue plane is shown at 3a.

6.6 SAVING STEERING FILE



When you are ready to save your steering file, click on the 'Steering File' tab. The name of the file automatically defaults to the QFlex model you are using. In this case 'QFlex32.bef'. A steering file is saved for each module in the array and given an individual number. For example, when you save the steering file for a QFlex 32, two files will be saved (QFlex32_box1.bef and QFlex32_box2.bef). Any number of steering files can be saved and quickly uploaded to your QFlex hardware individually. Instructions for uploading your steering file are covered in the 'Using Podware' section.



6.7 BALLOON DATA


EASE™ and CATT Acoustic™

Where more than one QFlex array is deployed in an installation it may be necessary or demanded to carry out a more resolute acoustical analysis of the room. To properly evaluate QFlex coverage in 3D you can export a configuration file from BeamEngine which can be used in Ease™ and CATT Acoustic™



Click on the 'Balloon File' tab.

The name of the file automatically defaults to the QFlex model you are using. In this case 'QFlex32.xhn' This name can be modified. The file is saved in ASCII format and can be imported into the third party programme and the resultant balloon data viewed.



6.8 BEAMENGINE – FREQUENTLY ASKED QUESTIONS

- Q. If I'm adjusting Master Beta, what LF driver utilization compromises do I suffer in adjusting to less than "1"?
- A. Master multiplication factor to apply to regularization factors beta given in global A.wf(woofer) and A.tw(tweeter). Normally masterbeta = 1, but it can be reduced to 0.1, trading some SPL for sharper directivity at the lower end of each sub-array's (tweeter or woofer) working range. The default settings will be fine in almost all applications.
- Q. Why do some SPL plots of different surfaces further into the room start from the X=0 position?
- A. The SPL-curves report the sound pressure along the venue items. For curves of ceiling venue items (pointing downwards) it does not make sense to position these along the x-axis, so all ceiling items start at x=0.
- Q. I noticed that I can skew the coverage pattern of the array by putting in differing SPL values for any SPL surfaces. Any caveats in doing so? I'm just trying to steer a bit more energy onto the balcony front where the sound booth
- A. You can vary the intensity of each beam separately as well as adjust the intensity from the front to the rear of each audience plane. You should also treat the target SPL inputs (SPL (x1) & SPL (x2)) as a tool to vary the intensity of the respective beams.

6.9 SOME DESIGN TIPS

In many applications a larger QFlex model at the front of the building will suffice. A single QFlex model has the capability of generating a number of independent beams and creating even SPL distribution over very large areas, so no need for delay loudspeakers.

Beware of mounting the loudspeaker too low. The venue will most probably be empty when demonstrating or commission the project. Remember that people stand up and sit. Make sure that when people stand they are not masking the sound at the back of the room.

For effective vocal reinforcement in venues with very long reverberation times, do not be tempted to use too small an array. A QFlex16 has effective steering control above 700Hz. The content of many vowel sounds occur below 700Hz. If the RT60 is particularly high, consider using a larger QFlex array.

Even in highly reverberant environments QFlex is capable of directing sound in a laser like manner. Sometimes to create some ambience it may be necessary to widen the beam slightly to create a natural sounding experience.

In very large venues where there may be features of the building which shadow the direct sound, for instance columns. Using smaller delayed QFlex models may be necessary to provide complete coverage. Remember – there is 1000ms of delay on board.

For more upbeat program material including music it may be necessary to compliment the QFlex with a subwoofer. As part of the Vnet family QFlex can be networked with a Vnet Subwoofer if necessary.


7 INSTALLING VNET SOFTWARE (PODWARE)

The latest version of Podware can be found at www.tannoy.com. Any new updates will automatically overwrite any existing versions.


1. Having downloaded the software, double click on the 'Setup.exe icon. The welcome screen will appear. Click **<Next>**



2. Select your destination Folder. Click **<Next>**




3. Confirm Installation. Click **<Next>**



4. If you accept the licence agreement check 'I Agree' and Click **<Next>**



5. The programme will begin installing



6. Installation Complete



8 USING VNET SOFTWARE (PODWARE)

Podware is a software package running under PC Windows™ for setting up and controlling any Tannoy Vnet device.

It is a clean Object Oriented package using the latest development technologies yielding intuitive ease of use and all the features you have come to expect and more. Podware is used for configuring installations as well as the live control and monitoring of devices during use. These devices may be connected individually using RS232 or USB. When participating in a networked system, Podware can control many devices via RS485 and Ethernet.

Podware is a precision tool for system control and is capable of being configured to display single controls and indicators, full interactive device panels or whole network views. Indeed, when networked, Podware can display information and controls from multiple devices on the same page.

8.1 OVERVIEW

The Vnet PodWare application will allow a PC computer running a 32-bit Windows™ operating system (NT, 2000, XP, Vista, ME*, 98*) to monitor and control a number of compatible devices via communications network. The deceptively simple intuitive user interface is PodWare's outward appearance of a very powerful, thoroughly engineered protocol engine, built on the latest software development technology.

PodWare can automatically discover devices connected to the network you tell it you would like to use. The connected devices are then presented to you in an organised tree ready for you to select panels you would like to display and manipulate

When devices are arranged in the main window, their default representation is a Monicon - an Icon which conveys basic monitoring status indication. This Icon can usually then be opened up to the full control panel by clicking on a navigation button.

Any number of Monicons and full panels may be displayed and organised on the screen automatically or manually. Each device type usually has a predefined Monicon and control panel associated with it, the latter containing controls for all the parameters you can adjust within the device. Adjusting any of the controls on the panel whilst 'on-line' will cause adjustments to be made in the relevant device in 'real time'.

A comprehensive set of features allow you to save and retrieve stored parameter sets, manipulate 'presets', etc.

*Note that whilst operation with Windows™ 98 or Millennium Edition is theoretically possible, this is not recommended because of the resource limitations these operating systems impose. If this is attempted, you should not attempt to run any other applications at the same time as PodWare, and we would recommend that you only open one or two control panels at a time.

8.2 LAYOUT


When PodWare is launched, its main window comprises three main areas:

- A 'tree' panel on the left for navigating among devices and panel
- A toolbar at the top with the most commonly used actions available at a single mouse click
- A control panel area (the remainder of the window) for device Monicons and control panels.

The user may adjust the size of the application window by dragging the handle at the bottom-right of the main application window. The 'tree' panel may be sized by dragging the split-line between the tree and the main control panel area.

8.3 MENUS

The menu system is arranged like so:



File

- Open - opens a file which contains parameters for the selected device
- Save - saves the current settings for the selected device in the current file name
- Save As - saves the current settings for the selected device under a new file name
- Load Factory Settings – updates factory settings in the selected device (See Loading Factory Settings)
- Open Device Clone – opens a file to clone the selected device
- Save Device Clone – saves the settings of the selected device into a cloning file (See Cloning a Device)
- Exit - closes the application

Preferences

- Show Bandwidth As – Allows you to set the units used in Bandwidth controls
- Show Delay As – Allows you to set the units used in Delay controls (See Controls)

Network

- Go Online - Allows communication with devices on the network
- Go Offline - Stops communication with devices on the network
- Com Port - Allows you to select which serial COM port you wish to use
- Launch Panels - Launches the control panels for all the devices in the network

Device

- Locate – to locate the selected device (e.g. wink the lights)
- Update Firmware - update firmware in the selected device (See Device Firmware)
- Add Device Panel – allows a panel for a device to be added to the layout off-line
- Properties – Lists device details which may be of interest for maintenance (See The selected Device)

Panel

- Tile Horizontally – arranges all the panels from left to right
- Tile Vertically – arranges all the panels from top to bottom
- Cascade – arranges all the panels in a heap from top-left to bottom-right

Help

- Help topics – opens the help file (in your HTML viewer)
- About this Application – shows copyright and version information

Some of these menu items have short-cuts using toolbar buttons. See Toolbar

8.4 TOOLBAR

The toolbar provides the following one-click functions:

Open

Opens a file which contains parameters for the selected device. A dialogue will appear, inviting you to choose a file to open.

Save

Saves the current settings for the selected device. If you have previously opened or saved a file, the settings will be saved in the same file name, otherwise, a dialogue will appear inviting you to enter a file name. If the settings have not changed since you last saved or opened a file, the icon will appear greyed out, indicating that a save is not necessary.

Online

Goes online/offline to/from the network. If a device cannot be found, an error will be reported. While PodWare remains on-line, this toolbar button is coloured green. It is red when off-line.

Locate

Flashes the indicators on the selected device (if online), to assist device identification, and as a quick check that communications are working. This only works when on-line.

Mute All

Mutes (or Un-Mutes) every device in the system. When the speaker in the button is red, the system is muted. A green speaker means un-muted. This has nothing to do with channel mutes, which operate completely independently. This state is not saved in devices; a power cycle will cause a device to default to un-muted.

Launch All Panels

Launches the control panels for all of the devices on the network. This only work when on-line.

Help

Launches Help topics

If you place the mouse cursor over a toolbar, text fill appear describing the action of the button. If this text does not show, click on the panel background.

See The Selected Device

8.5 COMMUNICATIONS

PodWare communicates with a device using a serial 'COM' port as a 'network' connection. This will usually be the COM port associated with the RS232 Serial port on your computer. You need to select the appropriate COM port for this in the Network menu.

If your computer does not have an RS232 serial port, a USB or Ethernet adaptor may be used to create one. Such an adaptor needs to create a 'Virtual Com Port' in order for it to be used with PodWare. Please refer to the installation instructions supplied with the adaptor. We cannot guarantee that all adaptors will work correctly however. Please consult your dealer for recommended adaptors.


It is strongly recommended that you use the dedicated Tannoy USB/232 interface (Tannoy part number 8001 4450). The user manual & drivers for this device can be found at www.tannoy.com.

When a network connection is open and actively connected to one or more compatible devices, the system is said to be 'On Line'. Whilst On-line, you can control the connected devices in 'real time', and continuously receive status information from the devices.

To go On-line, you can either select Device/Online from the menu, or press the Online toolbar button, which is a red triangle. If all is well, the triangle will turn green, indicating that you are 'On-line'.

Going Online

PodWare queries the network, searching for compatible devices. As PodWare finds each device, it will add it to the 'Devices' node of the Tree, along with text describing the model of the device, and the name of the device given by the user. Once all devices has been discovered, you are ready to start controlling the system by double-clicking a device icon in the Tree to launch a control panel.(see Launching a Panel)



If PodWare becomes unable to communicate with a device for some reason whilst on-line (such as a break in the network cable), the corresponding icon for it in the Devices node of the Tree will appear in red, indicating that control and monitoring on that device is invalid. Most devices will allow themselves to be 'rediscovered' automatically if such a cable break is repaired.

8.6 LAUNCHING A PANEL


Once the application is On-Line, and there are one or more devices in the Devices node of the tree, a panel may be launched for a given device in one of the following ways:

- By double-clicking on the appropriate Devices node of the Tree
- By dragging a Devices node to the Layout area of the main window
- By dragging a Devices node to the Panels node of the Tree
- By right-clicking on the Devices node and selecting Launch Panel from the context menu (see Device Context Menu)
- By selecting Launch All Panels, either from the Toolbar (see Toolbar), or from the Network menu (See Menus)

After a few seconds, the panel (or more usually, the reduced-size Monicon – see Monicons) will appear in the Layout part of the main window. At the same time, an icon for the device will appear in the Panels node of the Tree.

Once the panel appears, the application will take a few seconds while it copies the settings in the device to the control panel, as indicated by the progress bar at the bottom-right of the main window. (See Parameter Synchronisation)

This is now a fully functional real-time control panel for the connected device. A Monicon may be enlarged to a full-size control panel by using navigation buttons. (See Navigation).



Several control panels may be launched onto the Layout, so that the user can monitor the operation of several devices simultaneously. As each panel is added, another icon is added to the Layout node of the Tree, indicating the presence of another panel in the Layout.

The Panel menu has features for arranging the panels into regular neat patterns if required (see Menus).

To locate a panel for a particular device, just double-click on its icon in the Panels node of the Tree. This will bring the associated panel to the front, and highlight it (bring it into focus). (See Navigation).

A panel may be removed from the Layout by clicking on the 'X' in the top-right corner of the panel. This action will also remove the device icon from the Panels node of the Tree. The panel may be launched back onto the Layout by double-clicking on the Devices icon in the Tree.

8.7 CONTROLLING DEVICES – A QUICK OVERVIEW

When online the tree menus will show the connected VNET speakers on the network. Double clicking on the model on the tree view will open the control panel for each respective device. Each open panel will also appear on the tree view under panels . When online, Podware gathers information from the connected devices. Any parameters which have been adjusted by the user in previous sessions will be shown.

Each control panel can be positioned on the screen to represent its actual location position in the venue. When saving data the control panels co-ordinates are also saved so that it appears in the same location on the screen when data is recalled (see saving & recalling data).

The panels shown on the screenshot allows you to view what is going on inside the VNET product. As well as a mute button, there is a limiter meter which indicate signal level relative to the limiter threshold setting, input level meter, draw on the power supply, driver status indicators showing the status of each driver.

The arrow button (>>) at the top right hand side of the control panel will expand the control panel to reveal a host of parameters which can be viewed & adjusted.

8.8 PARAMETER SYNCHRONISATION

PodWare aims to always ensure that the control settings in the virtual control panel are always a faithful representation of the settings in the connected device. To achieve this, the parameters in the device are copied to the control panel when going online. This takes a few seconds to complete (see [Communications](#) and [Progress Bar](#)). Whilst online, any changes to the control settings will result in changes in the stored parameters in the devices, thus retaining synchronisation. When a file is opened online, the new settings are not only set in the control panel; they are also transferred to the device

8.9 PROGRESS BAR

The area in the status bar at the bottom-right of the application window will indicate progress of some operations. A coloured bar will extend to fill the extreme right-hand box, indicating progress from 0 to 100%, after which it will disappear. While in progress, the text to the left of the bar will indicate what operation is being performed. "Loading" will often be shown to indicate that the data is being transferred between the device and PodWare.

While the Progress Bar is showing activity, it is best not to perform any other actions in PodWare.

8.10 NAVIGATION

The Tree view on the left-hand side of the screen allows you to view the system. The two main nodes in the Tree are Devices, listing all the compatible devices found on the network, and Panels, listing all the control panels that have been launched onto the Layout. Control panels may be launched by double-clicking on, or dragging a Devices node (see [Launching a Panel](#)).

Clicking the '-' on one of the main Tree nodes will close that branch, allowing you to remove some detail from the Tree. Clicking the '+' will restore the full detail.

Panels will often have navigation buttons for changing the amount of detail seen (and size of the panel). A Monicon panel will have a '>' button for expanding it into a full control panel. Similarly, a full panel will often have a '<' button for reducing the amount of detail (and panel size).

8.11 THE SELECTED DEVICE

The "Selected Device" is the device to which operations from the Device menu will be applied, and to which device-related toolbar button actions (such as Locate, Save, Open) will be applied.

If a device is selected in the Tree view (by clicking on a device node or a panel node so that the text of the node highlights), then this is the selected device. If no device is selected in the tree, then the control panel in focus (the one whose colour is different to the others) will be the selected device. If there are no panels in the layout, and no device is selected in the Tree view, then no device is selected, and device-related operations will not work.

8.12 DEVICE CONTEXT MENU

By right-clicking on the node of a device in the Tree, a 'context menu' will appear, providing you with the following possible actions:

- Launch Panel – Launches the control panel for this device
- Rename Device – Allows the Device Name to be changed
- Update Firmware - Update firmware in this device (See Device Firmware)
- Locate Device – To locate this device (e.g. wink the lights)
- Properties – Lists device details which may be of interest for maintenance

If you do not wish to select any actions from the context menu, it can be dismissed by pressing the ESC key, or by clicking the mouse anywhere else in the application window.

8.13 CONTROL PANELS

Each panel will have a complete set of controls relating to the adjustable parameters within the device. Each control will contain the current parameter value (See Parameter Synchronisation). In some panels, Tabs are used to distinguish between different sections of the device.


Single parameters may be adjusted 'live' whilst 'On-line'.

Also see Controls

Panels will often have a tool bar, with buttons for executing commonly used functions such as File Open, File Save, Locate and Help (see ToolBar).


Main Control Panel

The EQ / Delay tab allows you to adjust the cabinet equalisation, High-pass filter, and delay. The cabinet equalisation allows you to adjust the frequency and Gain (boost/cut) for each of the equalisation filters, and the bandwidth of the parametric equalisers. The latter controls allow the responsiveness of the filters to be adjusted either as Octaves or Q, depending on the setting of Preferences>Show Bandwidth As. There is also a Low-shelf and a High-shelf filter, each with Frequency, Slope and Gain controls. A 'Frequency Response' curve shows the shape of each filter individually (by colour), and the combined effect of all equalisation (in white).



The Setup tab contains a 2-input mixer for adjusting the relative levels of the two audio inputs. If a digital input is fitted, then the Source may be changed to 'Digital', and the Digital mixer tab selected to control the mix between the two digital audio inputs. The steering file may also be loaded in this tab. See Loading Steering Data

The Properties/Options tab contains some properties of the loudspeaker. Here, you can enter a name for the loudspeaker (such as "Front Left"), and a name for the configuration (such as "EQ 8-11-2008"). Also viewable in this tab is the model name of the loudspeaker. The Maintenance area shows some details of how the loudspeaker has been used, with various counts of use and abuse.



The Logs area contains graphs of events against time, recording events over a period of up to three days. Since the loudspeaker cannot record any events whilst powered-off, breaks in a log due to power-downs are indicated by a discontinuity symbol 'II' in the log. The events recorded are: Thermal, which is the used thermal capacity, Amplifier Protect Gain, which is a measure of how much the loudspeaker is 'dimming' itself in order to protect itself from potential damage, Driver Protection, which is a measure of how much the loudspeaker is 'dimming' itself in order to protect the drivers from damage and Supply, which shows how the mains power voltage compares with nominal voltage. The data in a log can be exported by right-clicking on the log to launch a context menu, and selecting "copy log data to clipboard". The data could then be pasted into a spreadsheet for further analysis. Your dealer may ask you to do this if you have experienced a problem. Note that in addition to showing amplifier protection due to over-heating, the Amp Protection log will also show protection of individual amplifiers if they attempt to drive into an open circuit (if a driver has 'blown'). This will be shown as a protection gain of approximately -9dB.

Power Save


At the bottom left hand corner of the control panel there is a power save button. Activating this button will shut down the amplifier into a lower-power standby mode. The DSP section remains active. If you set the Power Save control to anything other than Manual, the loudspeaker will automatically go into power-save mode after a period without any audio signal, the time being set by this control. Whenever a signal is applied in this mode, the loudspeaker will rapidly wake-up.

You can change the view to the MonIcon panel by clicking the "<<" button.

8.14 LOADING STEERING DATA

Steering Files are generated in the BeamEngine software package (See Using BeamEngine)

The steering properties of the loudspeaker may be adjusted by loading a 'Beam Engine File' (*.bef) in the Setup tab in the main control panel. When the 'Open File' button is clicked, a dialogue will allow you to load a new .bef file. If there is more than one loudspeaker 'box' in the column, each .bef file produced by the beam design software will be for a given box. The box number will usually be appended to the name of the file. The number of each box is shown to the right of the device name in the Monicon. It is very important that each file is loaded to the appropriate box.




Note that when steering data is loaded into a loudspeaker, the data has to be stored internally, which takes a finite time. To avoid loss of steering data, do not remove the power from a loudspeaker for at least ten seconds after loading steering data. The same applies if you are loading a .dse Settings file which has steering data embedded into it.

8.15 MONICONS

Monicons are a condensed representation of a device, which show some monitoring status information, but few or no controls. Since these are quite small, they are a convenient way of arranging the devices on the main window in a manner meaningful to the application. Clicking the '>' button will cause the full control panel for the device to be displayed. (See [Navigation](#)).

This allows you to view what is going on inside the loudspeaker at a glance. There is a pair of input signal level meters showing the input signals, signal level meters for each group of drivers in the cabinet which indicate signal level relative to the limiter settings, a thermal meter showing the used thermal capacity of the amplifiers, and amplifier status indicators showing when an amplifier is protecting itself from damage due to abnormal operating conditions, and Driver indicators showing when the impedance of a driver is outside normal range, laid out in the same way as the physical drivers. Generally, the indicators show green whilst all is well and red when something is wrong.



Note that the Input meter on a Master displays the absolute signal level (in dBu) present on the input connector, and is unaffected by the input gain control. The input meter on a Slave displays the level of the signal passed to it by the Master, relative to full-scale, and is effected by the input gain on the Master. You may also mute the loudspeaker, and see the input gain. The gain can also be changed by typing a value into the Gain box. You can change the view to the main panel by clicking the ">>" button. At the top of the Monicon, the name of the device is shown, and to the right of this, the number of the box so that each box may be identified in a multi-box column.

8.16 CONTROLS

Controls have standardised properties that allow them to work in a consistent way across various control panels for different devices. Many controls will allow the mouse wheel to be used for fine adjustments, or the keyboard as an alternative (see [Keyboard Shortcuts](#)). When using the keyboard or the mouse wheel, it is necessary to have the control in question 'in focus'. You can bring a control into focus either by tabbing to it (using the Tab key), or by clicking on it with the mouse. Focus is often shown as a dotted rectangle around part of the control, or by the text in a control being highlighted, or by a solid outline being added to a button. Some controls may allow the units of measure used for displaying and adjusting values to be changed, such as Equaliser Bandwidths, which may be shown in Octaves or Q, or Delays, which may be shown in distance or delay units. The units of measure are selected in the Preferences menu (see [Menus](#)).

Drop-Down Selector boxes

These are for selecting one item from a number of possibilities in a list. Click the arrow on the right-hand end of the control to cause it to display a list of the options. Click on the text for that option to select it. If there are many options to choose from, a scroll-bar will be shown, allowing you to scroll up and down the list by clicking the scroll arrows. Note that once the control is highlighted, the PGUP, PGDWN and Arrow keys or the mouse wheel may also be used to change the selection.

Spin boxes

The value would normally be adjusted by clicking on the top button to increase the displayed value, or on the bottom button to reduce the displayed value. Holding the mouse button whilst on a button will after a short delay cause the repeat mechanism to repeatedly increment or decrement the value. Alternatively, values may be typed into the value box directly. To do this, click in the value box and type in the new value. The value you type in may include a minus sign, a decimal point, and/or an engineering multiplier, such as 'k' to signify a multiplication of 1000. This may appear at the end of the typed string, or may be used instead of a decimal point (such as 6k2 to mean 6200). Some controls may auto-range as the value changes. For example, delay controls in distance mode may change from mm to m as the distance increases beyond 999mm. If you wish to type a value into such a control, then metres will be assumed unless you specify mm (such as "53mm"). For the value to be accepted, you can either click outside the control (such as on another control), or press the Enter key. Once a control button is highlighted, the PGUP, PGDWN and Arrow keys or the mouse wheel may also be used to adjust the value.

Buttons

Buttons generally have two states; depressed (active) and non-depressed (inactive). Generally, the button will apply the condition that is labelled when it is depressed. The space bar may be used to activate a button which is in focus.

Radio buttons

These are laid out in mutually exclusive groups to select one of a number of options. Press the radio button to select it, which will cause any other button in the group to be deselected. Once a control in the group is highlighted, the PGUP, PGDWN and Arrow keys may also be used to change the selection.

Faders

Faders provide a linearly traversing button, which may be dragged using a pressed mouse to adjust the value. These sometimes also have an associated value box for showing the numerical value of the parameter. Once the control is highlighted, the PGUP and PGDWN keys may be used for coarse adjustment, and the Arrow keys or the mouse wheel may be used to for fine adjustment.

8.17 FILTER RESPONSE PANELS

Some panels provide a graphical representation of the response of one or more of the filters/equalisers in the device. These will usually consist of coloured semi-transparent filled areas representing individual filters, overlaid with a white curve line representing the overall response of a bank of filters/equaliser sections.

When the associated filter parameters are adjusted, you will see the curves responding so they always show the current response.

It will usually be possible to 'drag' the filter parameters with the computer mouse directly on the Response Panel. If you click anywhere in a Response Panel, you will see a set of 'drag handles' appear at the apexes of the individual filter response curves. These handles will usually have the same colour as the filter they relate to, and carry a number or letter to assist identification.

To change a filter parameter, place the mouse pointer over the drag handle, then press and hold the left mouse button while moving the mouse (vertically to change the filter gain, and horizontally to change the filter frequency). The filter With/Slope/Order may be adjusted either using the mouse wheel, or by holding the keyboard shift key whilst dragging the handle vertically.

The keyboard may also be used (see Keyboard Shortcuts).

Copy Graphics

To assist in preparing documentation etc, any response panel may be copied (to the Windows clipboard) by right-clicking on the panel and selecting Copy Image to Clipboard. The bitmap image may then be pasted into another application (such as word-processing), usually by selecting Edit>Paste in that application, or CTL+C.

Copy/Paste Settings

You can copy EQ settings from one channel to another on a given device, or copy EQ settings from one device to another. To do this simply right-click on the source panel (the one you want to copy from) and select Copy EQ Settings. Then on the destination response panel (the one you want to copy to), right-click and select Paste EQ Settings. You will be alerted to any problems such as the destination response panel not having enough EQ bands to reproduce the source EQ, or access to some or all of the bands being restricted due to security protection.

8.18 OFF-LINE OPERATION

You may launch a control panel for a device whilst off-line by using the menu feature Device>Add Device Panel. Clicking on this will cause a dialogue to be shown which allows you to choose the particular model of device you would like to add to the layout. Once you have chosen the model, click the Add button. The application will then be busy for a few seconds while the panel is constructed, after which it will appear in the Layout part of the window, and an icon for it will be added in the Panel part of the Tree. More device panels may then be added by making further device model selections and clicking Add. When you have added all the panels you need, click the Done button to dismiss the dialogue.

Off-line operation is useful either for demonstration or product familiarisation, or for creating setting files when a real device is not available.

Settings made on an off-line panel may be saved to a settings file by clicking the file Save icon on the panel. Similarly, a settings file may be loaded into the panel for further modification.

Note that when you go on-line to a network of devices, any off-line panels will first be dismissed. You can of course load a settings file you created offline into a device when on-line (See Saving Data).

8.19 SAVING & RECALLING DATA

Device Data may be saved to disk or opened from disk. PodWare Device Settings files (with file extension .dse) contain all the user data necessary to restore a device to exactly the same state as when the file was saved.

If the current settings have been changed since the last file save or file open, the Save Icon on the panel toolbar will be shown in solid colour. If the settings are already safe, the Save icon appears grey.

If a file is opened when on-line to devices, the new data will be sent to the device, overwriting whatever was in the device. A warning will be given before this is done. Data saved from one device can be reopened in another to save time inputting data. (Assuming settings are to be duplicated).

When you save a file, you will be invited to include steering data in the file. If you do this, opening the file into the same device or another device will reinstate the same steering settings. If you do not include steering data, then the user settings such as EQ etc remain independent from steering data. If you open a settings file which contains steering data, a warning will be given that the steering data will be overwritten. PodWare will always try to protect your data, warning you if you are attempting an action that could cause loss of data.

8.20 LOADING FACTORY SETTINGS

Using the File>Load Factory Settings menu option, you can update the basic factory settings which might be issued in future from Tannoy.

When you load factory settings into QFlex, the current user settings will be preserved since the factory settings will only overwrite the factory DSP settings rather than the User DSP settings. Depending on what type of file is supplied, the factory file may or may not include steering data. A warning will be given if you open a factory file which includes steering data, since this will overwrite any existing steering data.

For further information on loading factory settings, please see the main application help.

This procedure will apply to the currently selected device (See The Selected Device).

Once you have selected the menu item, you will be guided to select a Device Factory (.dfa) file to load. If you have a control panel for the device in view, this will automatically be dismissed for a time while loading takes place. The progress bar at the bottom-right of the application indicates when the process has finished, after which your control panel will reappear if you had launched one.

8.21 CLONING A DEVICE

There are several different categories of settings within a device which are manipulated by the various file types. The standard Device Settings file (.dse) will only manipulate those parameters which are under the control of the user. More of the settings may be changed by loading Factory Settings (see Loading Factory Settings). However, to create a completely duplicate device whose settings will be identical in every way, the Cloning facility may be used. To do this, select the device which you wish to clone FROM (see The Selected Device), then use File>Save Device Clone.

Once you have selected the menu item, you will be guided to choose a Device CLone (.dcl) file name to save. If you have a control panel for the device in view, this will automatically be dismissed for a time while saving takes place. The progress bar at the bottom-right of the application indicates when the process has finished, after which your control panel will reappear if you had launched one.

Now select the device you wish to clone TO, then use File>Open Device Clone. A similar process to that described above will allow you to choose the .dcl file to open. Once the process is complete, the two devices will be identical.



Clearly for this to make sense, the two device should be of the same type.

8.22 OPERATING MODE



A control input on the back of the loudspeaker allows you to select between two different sets of DSP settings (1 and 2) – see system connectivity. The currently active Operating Mode is indicated by the 'Active' box in the OpMode group box in the PodWare panel. You can select which Operating Mode you wish to edit by selecting the appropriate radio-button in the OpMode group box. Both modes may be edited simultaneously by selecting 'Edit Both'. Only when the Operating Mode is the same as the edited mode will changes you make be heard. Note however that if you make adjustments on the control panel when the active mode is different to the edit mode, the settings are changed and stored in the loudspeaker, but you will not be able to hear the changes until the active mode is changed to the one you have edited. A red indication will be shown in the OpMode group box when you are not listening to the mode you are editing.

Note that Parameter adjustments are automatically stored in the loudspeaker - it is not possible to do temporary changes then store them separately.

Example - Op Mode 1 with a particular EQ setting.
Input B Muted



Example – Op Mode 2 with an EQ setting for emergency paging.
 Input A muted.



Protection

Comprehensive protection features preserve the longevity of the amplifiers and drivers by continuously monitoring several critical parameters, and reducing the gain, or muting the amplifiers either temporarily or permanently depending on the nature and seriousness of the fault or misuse. The amplifiers will recover and restart if at all possible, but may remain shutdown if a serious fault persists.

Limiters deal with routine over-driving of the drivers, making sure that the drivers are not pushed too hard.

Minor faults are dealt with by slowly 'dimming' the loudspeaker, reducing the level to a sufficient degree and for a sufficient time that the amplifiers are able to recover gracefully without any user interaction. When the fault condition has passed, the amplifiers will slowly fade up to normal.

More serious faults may cause the amplifiers to mute while they recover, after which they will automatically re-energise and fade up, again without user interaction. If such a fault is found to be persistent however, the amplifiers may shut down permanently, flashing an indicator rapidly. A power cycle by the user is then required.

During power-up, the amplifiers will remain muted for a short time while checks are made that all is well. During this time, the Indicator will flash. The signal is then gently faded up.

Indication

Visible from the front of the loudspeaker is a Network indicator, which also winks for a few seconds when the 'Locate' feature is activated in PodWare. This allows you to confirm which control panel in PodWare is dealing with which physical loudspeaker.

Summary of indication:

- During Loudspeaker power-up: Indicator winks rapidly
- Loudspeaker has detected a fault: Indicator winks rapidly
- Locate feature activated in PodWare: Indicator winks
- Mute All activated: Indicator winks slowly

8.23 DEVICE PROPERTIES

By selecting Device>Properties from the menu (see Menus), or by selecting Properties from the Device Context Menu (see Device Context Menu), a dialogue will be shown listing some properties for the selected device (See The Selected Device). These are as follows:

Model Name: The Model Name/Number the type of device is usually known as (e.g. "QFlex 16 Master")

Device Name: The name given to this particular device by the user (e.g. "Left Proscenium"). This can usually be changed in a control panel, or in the Device Context Menu (see Device Context Menu)

Settings Name: The name given to the current set of parameter settings (e.g. "Bright vocal")

Firmware Model: A number describing the type of software running in the device.

Firmware Version: The version number of the firmware so you can tell if you have the latest. See Device Firmware

Handle: A 4-digit hexadecimal number which will uniquely identify this device on a network

Link Address: A hexadecimal number which the network will use for addressing this device.

Hardware Version: A number representing a variant of the hardware build of a given device type. This is rarely of concern to the user, but you may be asked to quote this value when discussing a problem with your dealer.

When you have finished with the dialogue, just click the Done button.

8.24 DEVICE FIRMWARE

Firmware is the software which runs inside the device. Most products which are controllable from PodWare have firmware which can be updated by the user.

Firmware is uniquely identified by two things:

1. The Firmware Model Number. This is not the model number of the product, but a number which uniquely describes the type of firmware used by the device. When updating firmware, the same firmware model must be used.
2. The Firmware Version Number. This describes the issue of the firmware update within a given model number. When updating firmware, the latest firmware Version Number for a given firmware Model Number would normally be selected. Firmware updates are usually supplied in .dfw (Device FirmWare) files. PodWare uses a .dfw file to load new firmware into a device.

➤ Firmware files are named like this: ****5678V1234.DFW

If you are using the very latest Version of Podware then you will be advised automatically when you go online if your device requires a firmware update

You can inspect the firmware Model and Version in the Device Properties dialogue.

To update the firmware in a device, see Menus or Device Context Menus.

At the bottom right hand side of the screen a blue bar will show the progress of the firmware update.

Do not power down the unit or disconnect any network cable during a firmware update.

During the update a red bar will show the progress of the firmware update (bottom right of screen).

The device will then power cycle automatically. The loudspeaker is now ready for normal operation.

8.25 KEYBOARD SHORTCUTS

PodWare supports the following 'shortcuts':

Tab	Move to next control
-----	----------------------

In value boxes:

CTL+C	Copy
CTL+V	Paste
CTL+X	Cut
CTL+Z	Undo

On Drop-down, Spin, Push, Fader and radio controls:

PgUp	Increase value (coarsely)
PgDown	Reduce value (coarsely)
Up/Right arrow	Increase value (finely)
Down/Left arrow	Reduce value (finely)

On push-button controls:

Space	Activate
-------	----------


On Filter Response Panels:

PgUp	Increase Width/Slope/Order value
PgDown	Reduce Width/Slope/Order value
Up arrow	Increase filter gain value
Down arrow	Reduce filter gain value
Right arrow	Increase filter frequency value
Left arrow	Reduce filter frequency value
Tab	Move to next filter
Shift	Used with mouse drag to adjust Width/Slope/Order value

9 HARDWARE CONFIGURATION


To avoid shipping very long products, QFlex products are modular, so it will be possible to assemble the components of a QFlex product on site. Each QFlex module incorporates a mains power supply, DSP platform with Vnet support, and audio amplification.

All of the required joining hardware and bracketry is included with each QFlex purchase. If you have purchased a QFlex 8 or a QFlex 16 there are no connecting plates or other joining hardware. Each QFlex carton is marked to show each modules position in the array.



There are 5 individual modules that make up the complete QFlex Range:

- a. 8 channel master unit (80014910)
- b. 8 channel slave unit (8001 4900)
- c. 16 channel master unit (8001 4890)
- d. 16 channel slave unit (top) (8001 4880)
- e. 16 channel slave unit (bottom) (8001 4870)



The joining hardware parts are packed with the QFlex modules in cardboard boxes which double as carton fillers. These will be marked 'HARDWARE'

The Table below shows the list of joining hardware parts and bracketry supplied with each QFlex model.

QFlex Product	Product number	Cabinet joining plate with hinges 7600 1770	Joining plate - side 7600 1880	Screws - 20off (4 spare) 7600 1881	Joining plate - rear 6883 0267	Wall bracket 8001 5330
QFlex 8	8004 0100	0	0	0	0	1
QFlex 16	8004 0110	0	0	0	0	1
QFlex 24	8004 0120	1	1	1	0	1
QFlex 32	8004 0130	1	1	1	0	1
QFlex 40	8004 0140	2	2	2	0	2
QFlex 48	8004 0150	2	3	3	1	2


- A QFlex array will consist of either just a master unit (QFlex 8 or 16) or a master unit with up to three additional slave units (QFlex 48)
- The master unit will always be positioned at the bottom of any speaker column and will be slightly longer to accommodate the connectors and power indicator.
- The top of the master unit will allow a slave unit to be mechanically fixed to it.
- The bottom of a slave unit will be designed to be mechanically fixed to the top of a master or slave unit.
- The top of a slave unit will be the same as the top of the master unit to allow another slave unit to be mechanically fixed to it.
- QFlex systems may be configured to enter a power saving standby mode either automatically or in response to a VNET™ command, returning to operating mode either upon the detection of audio or a 'power up' VNET™ command.
- QFlex products have analog and AES* audio inputs, and use VNET™ for monitoring and control.
- For mechanical integrity, thermal and EMC reasons, the electronics module is in a separate cavity from the transducers.
- QFlex products are designed to meet the safety requirements of UL60065 7th edition & EN60065 2002.
- QFlex meet the EMC requirements of Fcc15a and EN55103

* AES inputs will be included as standard in 2009

10 ASSEMBLY INSTRUCTIONS

10.1 QFLEX 8 & QFLEX 16 ASSEMBLY


With a QFlex 8 and QFlex all you need to do is remove the loudspeaker from the box and fix the wall bracket as shown below. The wall bracket can be hinged on the left or right pivot points. 3mm Allen grub screws allow the QFlex to be locked at the desired horizontal angle.



Having the hinge points on either side of the QFlex column allow the loudspeaker to be rotated at 90 degrees to the mounting structure allowing easy access to the input connector panel.

The installer must ensure that the mounting surface is capable of safely and securely supporting the loudspeaker. Seek help from architects, structural engineers or other specialists if in any doubt.

Suspending




The hinge points can be unscrewed and replaced with M8 threaded rod to facilitate the suspension of the QFlex 8 or 16 as shown.

It is recommended that threaded rod is used on both sides. This will allow the unit to hang straight.


10.2 WALL BRACKET MOUNTING CENTRES - QFLEX 8 & QFLEX 16

The Wall bracket should be fitted to the wall first with the aid of the paper template which came with the bottom module. It is recommended that you tape the template to the wall. When you are satisfied with the mounting locations, fix the bracket to the wall using the appropriate fixing screws.

QFlex 8



QFlex 16




10.3 QFLEX 24 & QFLEX 32 ASSEMBLY


It is recommended that you assemble the column horizontally on a flat surface. Lay some cloth or cardboard on the surface to avoid scratching the surface of the product during the assembly process.

In the hardware pack you will find one wall bracket and joining hardware consisting of one heavy joining plate with hinge points, two small link bars and M4 Phillips screws.

Place each module in its respective position on the assembly area keeping them slightly spaced apart. Take the flying RJ45 connector in the lower module and insert it into the RJ45 socket in the upper module. Take the flying AC mains connector in the lower module and insert it into the female connector in the upper module.



Align the two columns together as shown below.



Attach the joining plates in the three stages as shown. Only one wall bracket is required to mount the two modules. For flexibility the wall bracket can be mounted to either the top or the bottom column. The wall bracket can be hinged on the left or right pivot points. 3mm Allen grub screws allow the QFlex to be locked at the desired horizontal angle.


Having the hinge points on either side of the QFlex column allow the loudspeaker to be rotated at 90 degrees to the mounting structure allowing easy access to the input connector panel.

The installer must ensure that the mounting surface is capable of safely and securely supporting the loudspeaker. Seek help from architects, structural engineers or other specialists if in any doubt.


10.4 WALL BRACKET MOUNTING CENTRES - QFLEX 24 & QFLEX 32

The Wall bracket should be fitted to the wall first with the aid of the paper template which came with the bottom module. It is recommended that you tape the template to the wall. When you are satisfied with the mounting locations, fix the bracket to the wall using the appropriate fixing screws.

QFlex 24



QFlex 32




10.5 QFLEX 40 ASSEMBLY


It is recommended that you assemble the column horizontally on a flat surface. Lay some cloth or cardboard on the surface to avoid scratching the surface of the product during the assembly process.

In the hardware pack you will find two wall brackets and joining hardware consisting of two heavy joining plates with hinge points, four small link bars and M4 Phillips screws.

Place each module in its respective position on the assembly area keeping them slightly spaced apart. Take the flying RJ45 connector in the lower module and insert it into the RJ45 socket in the middle module. Take the flying AC mains connector in the lower module and insert it into the female connector in the middle module. Take the flying RJ45 connector in the middle module and insert it into the RJ45 socket in the top module. Take the flying AC mains connector in the middle module and insert it into the female connector in the top module.



Align the three columns together as shown below.



Attach the joining plates between each module in the three stages as shown.


The wall brackets can be hinged on the left or right pivot points. 3mm Allen grub screws allow the QFlex40 to be locked at the desired horizontal angle.

Having the hinge points on either side of the QFlex column allow the loudspeaker to be rotated at 90 degrees to the mounting structure allowing easy access to the input connector panel.

The installer must ensure that the mounting surface is capable of safely and securely supporting the loudspeaker. Seek help from architects, structural engineers or other specialists if in any doubt.

10.6 WALL BRACKET MOUNTING CENTRES - QFLEX 40

The Wall brackets should be fitted to the wall first with the aid of the paper template which came with the bottom module. It is recommended that you tape the template to the wall. When you are satisfied with the mounting locations, fix the brackets to the wall using the appropriate fixing screws.




10.7 QFLEX 48 ASSEMBLY


It is recommended that you assemble the column horizontally on a flat surface. Lay some cloth or cardboard on the surface to avoid scratching the surface of the product during the assembly process.

In the hardware pack you will find two wall brackets and joining hardware consisting of two heavy joining plates with hinge points, six small link bars and M4 Phillips screws.



Place each module in its respective position on the assembly area keeping them slightly spaced apart. Take the flying RJ45 connector in the first (bottom) module and insert it into the RJ45 socket in the second module. Take the flying AC mains connector in the first (bottom) module and insert it into the female connector in the second module. Take the flying RJ45 connector in the second module and insert it into the RJ45 socket in the third module. Take the flying AC mains connector in the second module and insert it into the female connector in the third module. Take the flying RJ45 connector in the third module and insert it into the RJ45 socket in the fourth (top) module. Take the flying AC mains connector in the third module and insert it into the female connector in the fourth (top) module.



Align the four columns together as shown below.



Note: The hinge plate without the pivot points must be installed between columns 3 & 4.




Attach the joining plates between each module in the three stages as shown.

The wall brackets can be hinged on the left or right pivot points. 3mm Allen grub screws allow the QFlex40 to be locked at the desired horizontal angle. The installer must ensure that the mounting surface is capable of safely and securely supporting the loudspeaker. Seek help from architects, structural engineers or other specialists if in any doubt.



10.8 WALL BRACKET MOUNTING CENTRES - QFLEX 48

The Wall brackets should be fitted to the wall first with the aid of the paper template which came with the bottom module. It is recommended that you tape the template to the wall. When you are satisfied with the mounting locations, fix the brackets to the wall using the appropriate fixing screws.



11 SYSTEM CONNECTIVITY

- In any QFlex product the bottom unit will incorporate all the external user connectivity for a column (Shown below).
- The connectors are located towards the bottom of the rear panel and will not be visible when installation is complete.
- Connections are accessed by the removal of an access plate which will require the use of a Philips screwdriver.
- There is no mains power switch. An external fused and switched mains spur will be required.
- There is no user accessible mains fuse.
- There are two balanced analog audio inputs labeled A and B.
- Analog inputs A and B are on a 6 way phoenix (pluggable terminal block) connector.
- Analog link outputs A and B are on a 6 way phoenix (pluggable terminal block) connector.
- The analog input and link signals are connected directly in parallel.



12 AUDIO CONNECTIONS –

The signal input & link connectors are fully balanced.

When connecting a balanced signal be sure to wire to the following standard:-

Hot (+), Cold (-), Shield (GND)


In a standard balanced interconnection there are two signal conductors and a shield. The shield is normally referenced to ground at one or both ends. Many times the shield is lifted at one end, usually at the input to eliminate “ground loops” or noise. The problem with this approach is that while it may reduce hum, the shields act as radio antennas and pickup radio frequency interference from the environment.

Multiple enclosures may be driven from a single audio source; simply connect the signal source output into the first input socket, and patch that speakers link to the next speakers input & so on.

13 NETWORK CONNECTIONS (Vnet in & Link)

Interconnection between the network computer and the speakers is very straight forward, using twisted pair cable and simple connectors. The USB to Vnet (RS485) interface operates on a shared bus so that a single computer can control any QFlex loudspeaker on the bus, and the computer may gather status information from any device on the bus. Each module contains a unique address so that no user input will be required to configure network nodes.

It is only data that is carried over the network to control setup functions & ongoing system diagnostics, therefore if a network fault occurs, audio can still be delivered. This alleviates the problem of total system failure through a single system controller going down. As each loudspeaker controls its own DSP functions any unforeseen failure would be isolated to only that particular node.



Use of the Tannoy USB to Vnet interface (Part No. 8001 4150) is highly recommended. The interface and QFlex loudspeakers use RJ45 connector's through, so no need to use non standard connections when using 3rd party interfaces.

The Vnet network uses the RS-485 protocol for sending serial data. It uses a pair of wires to send a differential signal over distances up to 4000 feet (1200m) without a repeater. The differential signal makes it very robust, RS-485 is one of the most popular communications methods used in industrial applications where its noise immunity and long-distance capability are a perfect fit.

IMPORTANT: Always run a signal ground with RS-485

Connections from the USB to Vnet device to the QFlex speaker is as follows:-

From USB – Vnet Interface (or third party interface)	Device RJ45 To Vnet Network
B+	Pin 1
A-	Pin 2
GND	Pin 5

Network connections between nodes are via rugged Neutrik ethercon connectors; these are high quality and are compatible with standard RJ45 plugs. Node connections are made using standard RJ45 connectors and CAT5 cable. Long runs should be solid core, but standard is fine. The implication is that stranded is more robust and less prone to breakage, it is therefore suggested that solid should be used for install applications while stranded is better suited to rental applications. Cabinets can be daisy chained or linked in a star configuration, or a combination of both. Quality termination of all connectors at each node is essential for the network to function correctly.

Linking QFlex Cabinets -


The table below shows the standard straight-through convention for CAT5 patch cables (clip down). These can be used between network nodes. Bear in mind though that only Pins 1, 2, & 5 are used to link the network together.

Pin 1 (pin No.)	Pin 2 (pin No.)	Colour
1	1	White/Orange
2	2	Orange
3	3	White/Green
4	4	Blue
5	5	White/Blue
6	6	Green
7	7	White/Brown
8	8	Brown

To aid the construction of very large networks each speaker provides a source of power (+12Volts) on the network Link connector that can be used to seamlessly power network extenders or repeaters that large networks may require. This power can be located on pin 4 on the NETWORK LINK connector. This power is passed between the NETWORK IN & NETWORK LINK connectors if the speaker is powered off to ensure that upstream Vnet powered devices continue to receive power.

14 POWER

The QFlex unit comes supplied with the mains input connector. It can be located in the mains input socket. Wire the mains input connector as shown below.




Maximum long term power requirements for QFlex models are as follows –

Model	Max Power req.
QFlex 8	220 watts
QFlex 16	280 watts
QFlex 24	500 watts
QFlex 32	560 watts
QFlex 40	780 watts
QFlex 48	1000 watts

The supply system is designed to generate its nominal voltages when supplied from 100V – 230V 50Hz/60Hz mains. BROWNOUT will be indicated to the DSP if the mains supply voltage drops below a level where performance will be impaired. Normal operation will automatically resume when the mains recovers.

15 CABLE MANAGEMENT



All connections (AC, Network, and Signal) are accessed at the bottom of the QFlex column. This allows for neat, unobtrusive cable management in your installation.

16 CONTROL INPUTS (SYSTEM INTEGRITY & EMERGENCY PROVISION)

Status control

The system will indicate that it is powered up and working correctly by pulling in a single pole two way relay.

If a fault is detected in either the master unit or any slave units the FAULT relay will be de-energized. This standard feature allows the means of triggering an external remotely located alarm/indicator (not supplied).

The relay contacts will be rated to carry 500mA at 50VDC.

All three relay contacts are on the Phoenix connector (shown above)

The relay contacts are 'volt free', i.e. there is no electrical connection between any of the relay contacts and the QFlex electronics.

Mode control

It will be possible to make the system change its operating mode in the event of an emergency. For example, switch to a different audio input with different EQ.

The operating mode change can be activated by either of two means:

- a. an input line (line X) on the master unit being grounded or released (by an external switch, relay or open collector output etc).
- b. an input line (line Y) on the master unit detecting the presence or absence of an externally applied voltage greater than +4.5V.

The operating mode change connections are on the Phoenix connector (shown above)

Two Operating Modes (presets) are available – Operating Mode 1 and Operating Mode 2. These allow differences in input processing and input selection to be programmed, and selected by means of the Operating Mode control inputs.

Since input selection and input mixing may be automatically adjusted using Operating Modes, this may be useful for emergency evacuation (Voice Alarm) purposes for example. The Operating Mode thus triggered for VA could select the B input and may have different equalization and gain to the normal Operating Mode.

Since there are two different ways of selecting the Operating Mode using the Operating Mode control inputs, the particular Operating Mode used for VA could be either Operating Mode 1 or Operating Mode 2 depending on the way the system is used.

Although Operating Mode selection is only applied to Master units, the effect will be on all members of the QFlex column since input selection and input processing is for the entire column.

Setting up each operating mode is carried out within the Vnet software package (Podware). Instructions can be found in the Vnet Software operation section of this user manual.

17 INDICATORS

There is a dim green LED on the back of each QFlex master unit (master) that will illuminate if the PSU is running. All modules within a QFlex product have a blue 'LOCATE' LED visible from the front of the unit, operating as follows :

- a. it will illuminate for a few seconds when power is applied and the system initialises
- b. it will stay illuminated if the system fails to initialise
- c. it will flash for a few seconds if the LOCATE (wink) button for that speaker is pressed on the PodWare control panel

It will flash continuously if any fault that causes the FAULT relay to be dropped is detected.

18 SERVICE PARTS

Driver Kit - Type 0803 (3" driver) - 7900 1075

Driver Kit - Type 1004 (4" driver) - 7900 1076

Tweeter Array - 7900 1077

Amplifier Master 8 Way - 7900 1078

Amplifier Master 16 Way - 7900 1079


Amplifier Slave 8 Way - 7900 1080

Amplifier Slave 16 Way - 7900 1081


Grille 8 Way - 7900 1082

Grille Mater 16 Way - 7900 1083


Grille Slave 16 Way - 7900 1087




QFlex 8



QFlex 16



QFlex 24



QFlex 32



QFlex 40



QFlex 48

19 SPECIFICATIONS

	QFlex 8	QFlex 16	QFlex 24
Configuration			
4" LF	8		8
3" LF		8	8
1" HF		8	8
No. of Amp Channels			
100W(RMS) @ 4 Ohms	8	16	24
Vertical Dispersion	Variable between 10 - 100 degrees (Asymmetric & multiple beams may also be generated)		
Frequency Range	110Hz - 4kHz	130Hz - 20kHz	110Hz - 20kHz
Horizontal Dispersion	120 degrees	120 degrees	120 degrees
Aiming Angle Limit	+/- 70 degrees	+/- 70 degrees	+/- 70 degrees
LF Beam Control Limit	700Hz	700Hz	400Hz
Maximum SPL @ 100ft (30m)*	92dB	94dB/96dB	
Column Height	840mm (33")	744mm (29.3")	1483mm (58.4")
Column Width	171.5mm (6.7")	171.5mm (6.7")	171.5mm (6.7")
Column Depth	150mm (5.9")	150mm (5.9")	150mm (5.9")
Typical Application Distance**	20m (66ft.)	25m (82ft.)	40m (131ft.)
Sample Rate	96kHz	96kHz	96kHz
Audio Inputs	Analogue & AES/EBU	Analogue & AES/EBU	Analogue & AES/EBU
Weight inc hardware	15.25kg (33.6 lbs)	14.25kg (31.4 bs)	26.25kg (58.4 lbs)

* Average SPL (1kHz – 8kHz). Based on a mounting height of 10m (33ft) and a target area @ 30m (98.5ft) and 10m (33ft) wide. Maximum attainable SPL is dependant on the dimension of the target area(s). Exact figures can be derived in the BeamEngine™ programme.

** Based on the above venue criteria achieving 95dB SPL at the quoted distance.

	QFlex 32	QFlex 40	QFlex 48
Configuration			
4" LF		8	16
3" LF	16	16	16
1" HF	16	16	16
No. of Amp Channels			
100W(RMS) @ 4 Ohms	32	40	48
Vertical Dispersion	Variable between 10 - 100 degrees (Asymmetric & multiple beams may also be generated)		
Frequency Range	130Hz - 20kHz	110Hz - 20kHz	110Hz - 20kHz
Horizontal Dispersion	120 degrees	120 degrees	120 degrees
Aiming Angle Limit	+/- 70 degrees	+/- 70 degrees	+/- 70 degrees
LF Beam Control Limit	400Hz	250Hz	200Hz
Maximum SPL @ 100ft (30m)*	100dB	100dB	101.5dB
Column Height	1387mm (54.6")	2127mm (83.75")	2967mm (116.8")
Column Width	171.5mm (6.7")	171.5mm (6.7")	171.5mm (6.7")
Column Depth	150mm (5.9")	150mm (5.9")	150mm (5.9")
Typical Application Distance**	50m (165ft.)	70m (231ft.)	80m (263ft.)
Sample Rate	96kHz	96kHz	96kHz
Audio Inputs	Analogue & AES/EBU	Analogue & AES/EBU	Analogue & AES/EBU
Weight inc hardware	25.25kg (55.7 lbs)	38.5kg (84.9 lbs)	51.5kg (113.6 lbs)

20 WARRANTY

No maintenance of the QFlex loudspeakers is necessary.

Tannoy QFlex products are covered by a 3 year warranty from the date of manufacture, subject to the absence of misuse, overload or accidental damage. Claims will not be considered if the serial number has been altered or removed. Work under warranty should only be carried out by a Tannoy Professional dealer or service agent. This warranty in no way affects your statutory rights. For further information please contact your dealer or distributor in your country. If you cannot locate your distributor please contact

Customer Services, Tannoy Ltd at the address given below.

Customer Services, Tannoy Ltd., Rosehall Industrial Estate, Coatbridge, Strathclyde, ML5 4TF, Scotland.

Telephone: 01236 420199 (National)
+44 1236 420199 (International)
Fax: 01236 428230 (National)
+44 1236 428230 (International)

E-Mail: prosales@tannoy.com

DO NOT SHIP ANY PRODUCT TO TANNOY WITHOUT PREVIOUS AUTHORISATION

Our policy commits us to incorporating improvements to our products through continuous research and development. Please confirm current specifications for critical applications with your supplier.

tannoy.com

Tannoy United Kingdom	T: 00 44 (0) 1236 420199	E: enquiries@tannoy.com
Tannoy Deutschland	T: 00 49 (180) 1111 881	E: enquiries@tannoy.com
Tannoy France	T: 00 33 (0)1 7036 7473	E: ventes@tannoy.com
TC Group Americas	T: 00 1 (519) 745 1158	E: info@tcgroup-americas.com



Tannoy adopts a policy of continuous improvement and product specification is subject to change.