t.c.electronic (c)

WIZARD II

PC13003-3

CN4
CN1 MIDI out
CN3 MIDI thru
CN2 MIDI in
CN6
CN19 EXT. SYNC IN
CN13 OUT
CN14 IN
CN7
CN8
AES/EBU IN
AES/EBU OUT
S/PDIF IN/OUTPUT
IN : upper
OUT : lower
JTAG
DSP
Pedal in
JUMPER SETTING :
Please refer to : Service manual
FLASH
SRAM
MPU
WORK
DARC 3
SOUND RAM
DGND
PLL CIRCUIT
FRONT CONNECTOR
PCMCIA CONNECTOR
BATTERY
Exchange procedure :
Refer to service manual
3.3Volt
DGND
+5V
RIGHT OUTPUT
LEFT OUTPUT
RIGHT INPUT
LEFT INPUT
AGND
24-BIT DA CONVERTER
24-BIT AD CONVERTER
AD AMP
GAIN
+15V
-15V
+48V
+4.8V
SB-VCC VIOLET
+5V-SB BROWN
+5V RED
DGND BLACK
PGND GREY
AGND BLUE
-15V YELLOW
+15V ORANGE
+48V WHITE