

<b>Service Note</b>		
Product	Description:	Service note no.
<b>G-Major D-Two</b>	<b>Mono input sense doesn't work</b>	<b>722 10 T005</b>

## **IMPORTANT:**

Modification should only be carried out by authorized technicians.

We have found that we have shipped new G-Majors and D-Twos with Mainboard version P16001-6, which, if configured with jack I/O, SHOULD HAVE HAD two 0E (R96 and R113) resistors mounted. This means that the MONO input sense doesn't work.

### **The serial number range is:**

G-Majors from serial number **3411771** to **3412671**  
D-Twos from serial number **3113081** to **3113380**  
(we have not made any other products with this fault)

### **Symptoms for G-Major:**

- Right input meter doesn't show signal when using left(mono) input only.
- No chorus (using left in / left out only)
- No dry output on right output if using left(mono) input only.

### **Symptoms for D-Two:**

- Right input meter doesn't show signal when using left(mono) input only.
- Reverse effect doesn't work (using left(mono) input only)
- No dry output on right output if inputting on left(mono) only.

**REMEDY:** Short the pads for each resistor, R96 & R113, with solder or mount two 0 ohm (SMD0805) resistors.

R96 is located between left and right input jack sockets

R113 is located between right input and left output jack sockets

Please also refer to the "zoom-in" on the circuit board on the following page.