

TCCode	Description	Service level		
		1	2	3
Front section				
7B80521001	G-Major Front PCB w/display This is not available any longer MPU with program. Please see at the bottom		X	X
7B80522001	G-Major Display			X
7E59700101	Flat Ribbon Cable With 2x10 Pin Connect.			X
7E58200701	G-Major Front Panel, DR-1020-2 This is not available any longer	X	X	X
7E33800501	Power Button, DR-01113	X	X	X
7E34000201	Power switch SW/SPPH43 ALPS:SPPH43-*W-A			X
7E33905011	Small Plastic knob	X	X	X
7E12200101	10k 20% POT/RK09K113 POTENTIOMETER ALPS:RK09K113			X
7E33801201	Inner Knob, for Dual encoder, DR-01117-A	X	X	X
7E33801301	DR01118-B, Dual Encoder Outer knob	X	X	X
7E33801399	10 pack DR01118-B, Dual Encoder Outer knob	X	X	X
7E34000301	ENCODER,ENC/EC12E24204			X
7E34000801	Inner ENCODER w/ push function			X
7E34000701	Outer ENCODER, ENC/SRGP10-1			X
7E57600601	Vlies For Dual Encoder, DR-01031-A	X	X	X
7E33800602	Console For Button, DR-01104	X	X	X
7E33800802	DR01108-1, Inlet For Button With Led			
7E33902602	"NOISE GATE", Cap For Button With LED	X	X	X
7E33902702	"LEVELS ALL", Cap For Button With LED	X	X	X
7E33902802	"COMP", Cap For Button With LED	X	X	X
7E33902902	"CHO/FLA", Cap For Button With LED	X	X	X
7E33903002	"FILTER/MOD", Cap For Button With LED	X	X	X
7E33903102	"PITCH", Cap For Button With LED	X	X	X
7E33903202	"DELAY", Cap For Button With LED	X	X	X
7E33903302	"REVERB", Cap For Button With LED	X	X	X
7E33900102	"ROUTING", Cap For Button With LED	X	X	X
7E33903802	"MOD", Cap For Button With LED	X	X	X
7E33903702	"MIDI/UTIL", Cap For Button With LED	X	X	X
7E33900202	"I/O", Cap For Button With LED	X	X	X
7E33901102	"RECALL", Cap For Button With LED	X	X	X
7E33900902	"STORE", Cap For Button With LED	X	X	X
7E33900302	"TAP", Cap For Button With LED	X	X	X
7E33903602	"BYPASS ALL", Cap For Button With LED	X	X	X
7E49100101	MAX809 RESET CIRCUIT 3 PIN 3.08V			X
7E56700201	Plastic Spacer For Front Panel, double	X	X	X


Chassis				
7E58100102	Bottom Plate DR-01041-D	x	x	x
7E58100301	Side Plate, Diecasted Al DR-01002-6	x	x	x
Main board				
7B80110501	G-Major main board with Flash		x	x
7E48400801	G-Major, FLASH W/Program		x	x
7E33000101	24.576MHz HC49U 30PPM CRYSTAL			x
7E33000201	22.5792Mhz XTAL\HC49 30PPM CRYSTAL			x
7E36600101	MMBZ15VDLT1 EMI SUPPRESSOR DIODE SOT23			x
7E39900101	DG441 QUAD SPST ANALOG SWITCH SO16			x
7E48000105	1MX16 DRAM SOJ-42			x
7E48100106	128kx8 HIGH SPEED SRAM SOJ32			x
7E49000101	XCB56362PV100 DSP QFP144-3			x
7E49100301	AK4524VF 24-BIT 96kHz CODEC SSOP28			x
7E49100601	CS8414-CS DIGITAL AUDIO RECIEVER SSOP28			x
7E52200301	S4-BBB-PCC STEREO JACK CONNECTOR			x
7E58200401	Jack Spacer Black Plastic DR-01025		x	x
Relay board				
7B80523001	G-Major Relay PCB		x	x
7E59700201	Flat Ribbon Cable With 2x5 Pin Connect.			x
7E52200301	S4-BBB-PCC STEREO JACK CONNECTOR			x
Power Supply				
7E50000101	Manhattan Power Supply Unit		x	x
Miscellaneous				
E54700202	Cable U.S.A. Black 3x18 AWG SVT 180 cm.	x	x	x
E54700102	Cable EU Europe Black 3x0.75mm H05VV-F 180 cm	x	x	x
547004011	Cable UK with 5 Amp fuse Black Rewireable Female - UK plug	x	x	x

Regarding programmed MPU there are two types of housing. Please refer to numbers and picture below

7E49000215	G-Major MPU, AT90LS8535-4JC W/program.	Old PLCC type		x
7E49000225	G-Major ATMEGA8535L-8AU Microcontroller TQFP-44 W/program.	NEW TQFP type		x

New: TQFP

Old type: PLCC



Please disregard printing on label