

G-Natural				
TC order no:	Part name.	Service level		
		1	2	3
Front.				
7B82211001	Front PCB-A G-Natural OBSOLETE		x	x
7E33600901	LCD Display MC2402A-SYL 2X24CH Y/G			x
7E58204512	Footswitch TOP for AC/EC Front, DR05022-E	x	x	x
7E34001411	R13-85 Switch (Footswitch)			x
7E34001499	R13-85 Switch, 10 pcs. package			x
7E57505411	Footswitch Lightguide Ring DR-05130_C	x	x	x
7E57505711	Footswitch Nut DR-05131-B	x	x	x
7E57505111	Switch Cap DR-05125-C	x	x	x
7E57505211	Switch Lichtguide DR-05126-C	x	x	x
7E57505011	Overmolded Knob DR-05124-D	x	x	x
Mainboard.				
7B82213001	Mainboard PCB-A G-Natural		x	x
7E48403411	G-Natural Flash W/Prog		x	x
7E48000105	DRAM KM416V1000 CJ-5			x
7E48100106	128kX8 HIGH SPEED SRAM SOJ32-400Mill			x
7E49000101	DSP56362PV120 DSP QFP144-3			x
Chassis.				
7E56501111	Shim Ring 8x14, BN1976, Art. No. 3045431	x	x	x
7E56301611	M3x8 Hexalobular Black - (BN15857)	x	x	x
7E59802011	U Type Cabinet Handle - Black Steel	x	x	x
7E57600711	Rubber Bottom	x	x	x
7E59801011	Mounting washer for handle - Black steel	x	x	x
7E59106311	Lens plate for G-Natural	x	x	x
Mic. Amp.				
7B81123002	Mic. Amp. Voice Live / G-Natural		x	x
Power Supply				
7E50000101	Manhattan Power Supply		x	x
547003012	Cable EU Europe Black 3x0.75mm H05VV-F 180 cm	x	x	x
547007012	Cable Australia 3x0.75mm 250 cm	x	x	x
Miscellaneous.				
7E54300811	DR05580-A, Wire harness G-Natural Switch/LED ring			x
7E59700101	Ribbon Cable Front to Main		x	x