

Nova Reverb					
TC order no:	Part name.	SERVICE LEVEL			
		1	2	3	
Front.					
7F84012001	PCBA, P22652, Nova Reverb (G1) UI Board		X	X	
7E57504111	Overmolded knob for HANS DR05113-B	X	X	X	
7E57504211	Switch cap for HANS DR05114-C	X	X	X	
7E57504311	Switch light pipe for HANS DR05115-B	X	X	X	
7E57504411	Light bar for HANS DR05116-C	X	X	X	
7E34001411	R13-85 Switch				X
7E34001499	10 pcs package. R13-85 Switch				x
7E57504611	Foot switch collar for HANS DR05117-C	X	X	X	
7E12201111	Potmeter, 10K0, 11mm, Linear				X
7E12201211	Potentiometer 11mm Center snap				X
7E49004211	ATmega88 AVR QFP32/P08 (HANS 4M+3C)				X
7E59105911	Acrylic top lens for Nova Reverb		X	X	
Main.					
7F84011013	PCBA, P22612 Mainboard Nova Delay iB modified (also for Nova Reverb)		X	X	
7E48404715	512kx8 39VF040 FLASH To Nova Reverb				X
7E31701511	7-Segment, Bright RED				X
7E34000501	JTP1240G TACT switch w/ LED Green				X
7E48000105	1MX16 DRAM SOJ-42				X
7E48100106	128kx8 HIGH SPEED SRAM SOJ32-400Mill				X
7E49000101	DSP56362PV120 DSP QFP144-3				X
7E49100713	AK4620BVF 24bit 192Khz Codec - VSOP				X
7E52203611	6,3mm_1/4" Stereo Jack, Right Angle, PCB Mount				X
7E52300011	DC Power Connector				X
Power supply.					
960899002	PowerPlug 12V	X	X	X	
E52304011	Mains plug Australia for TC PowerPlug PSU	X	X	X	
Miscellaneous.					
7E54700801	Ribbon Cable for UI board				X
795299998	MIDI s/w upload board				X
Chassis.					
7E57601411	DR05112-C, Non-slip Rubber Mat for HANS	X	X	X	
7E58103712	HANS Right end cap DR05020-B	X	X	X	
7E58103612	HANS Left end cap DR05019-B	X	X	X	