

BMC-2

TC order no:	Part name.	SERVICE LEVEL		
		1	2	3
Front - UI.				
7E58208121	Sampel DR06028-B Encoder - DR06029-C Knob - BN24 M3x10 screw	X	X	X
7E33905011	Plastic knob Ø10 Button with "-"	X	X	X
7E33801401	DR01115-C, Inner Button 4X4 - Clear			X
7E33801501	DR01116-A, Cap for Button 4X4		X	X
7E33801451	DR01115-C, Inner Button 4X4 - Black			X
7F82812003	PCBA, P19344, BMC-2 UI		X	X
Main.				
7F82811003	PCBA, P19343, BMC-2 Mainboard		X	X
7E52300011	DC Power Connector			X
ADAT.				
7F81741002	PCBA, P19401, Konnekt 24D/BMC-2 ADAT		X	X
Power supply.				
960899002	PSU base PowerPlug12V/1A Level VI	X	X	X
E52304011	Mains plug Australia for Honor PSU Level VI	X	X	X
Miscellaneous.				
7E52100311	TosLink female to 3.5mm Mini-Plug male adapter	X	X	X
7E54702111	Headphone cable for BMC-2	X	X	X
725000001	CLI cable for service			X