

Part number	Part name.	Service level		
		1	2	3
Mainboard				
7F82720097	PCBA, P18111, Mainboard for BG250 112 incl. firmware		X	X
7E52200301	S4-BBB-PCC STEREO JACK CONNECTOR			X
UI				
7F82722001	PCBA, P18115, UI board for BG250 AMP module		X	X
7E12200201	10K RP11A11VB2 POTENTIOMETER 20%			X
7E34001011	Push Switch JTP1239			X
7E52200301	S4-BBB-PCC STEREO JACK CONNECTOR			X
PSU				
7F82721001	PCBA, P18114, PSU board for BG250 AMP module		X	X
7E11701811	NTC 10R 5.1W leaded			X
7E20404711	22n, 400V, 5%, Film cap, lead			X
Miscellaneous				
7E54704811	DR09925-A BG250 24 pol ribbon-cable for UI PCB 2mm		X	X
7E57510611	DR09102-B, BG250 Plastic Knob, Black	X	X	X
7E33806811	DR09102-B, BG250 Plastic knob, White	X	X	X
7E33802041	DR03103-C, 6,5mm Pushbutton	X	X	X
7E54602611	VoiceTone/Erik USB Cable, A plug to MINI B plug, 1,0m	X	X	X
7E54602811	Cable 1x3.5mm jack - BG250 > 1x3.5mm jack - 60cm	X	X	X
CAB				
7E58120211	DR09122- Metal Grill for BG250 112		X	X
7E61602011	12" Driver unit 99-01-0TC300-01		X	X
7E61601711	HF piezo driver unit BG250 - coil boost HD410		X	X
7E57507511	TCE logo for Bass Cabinets - 1097	X	X	X