

Part number	Part name.	Service level		
		1	2	3
<b>Mainboard</b>				
7F82720095	PCBA, P18111, Mainboard for BG250 AMP module		X	X
7E52200301	S4-BBB-PCC STEREO JACK CONNECTOR			X
<b>UI</b>				
7F82723001	PCBA, P18116, 1192, UI board for BH250		X	X
7E12200201	10K RP11A11VB2 POTENTIOMETER 20%			X
7E34003711	Erik Toggle switch 2 positions			X
7E52200301	S4-BBB-PCC STEREO JACK CONNECTOR			X
<b>PSU</b>				
7F82721001	PCBA, P18114, PSU board for BG250 AMP module		X	X
7E11701811	NTC 10R 5.1W leaded			X
7E20404711	22n, 400V, 5%, Film cap, lead			X
<b>Miscellaneous</b>				
7E54704811	DR09925-A BG250 24 pol ribbon-cable for UI PCB 2mm		X	X
7E57510611	DR09102-B, BG250 Plastic Knob, Black	X	X	X
7E33806811	DR09102-B, BG250 Plastic knob, White	X	X	X
7E33802041	DR03103-C, 6,5mm Pushbutton	X	X	X
7E54602611	VoiceTone/Erik USB Cable, A plug to MINI B plug, 1,0m	X	X	X
7E54602811	Cable 1x3.5mm jack - BG250 > 1x3.5mm jack - 60cm	X	X	X
<b>CAB</b>				
7E58120311	DR09121-A Metal Grill for BG250 208		X	X
7E61602111	8" Driver unit 99-01-TC200A-01		X	X
7E57507511	TCE logo for Bass Cabinets - 1097	X	X	X
7E58116815	DR09111-F Bottom plate HeadLow			X