

# Blacksmith

## Part list

Part number	Part name.	Service level		
		1	2	3
<b>Utility board</b>				
731015011	Blacksmith Service P18508, Utility board		x	x
<b>Front LED.</b>				
731137011	Blacksmith Service P18505, Front LED board		x	x
7E36704111	Chip LED 0402 White			x
<b>Front Encoder</b>				
731135011	Blacksmith Service P18506, Front Encoder board		x	x
7E34000401	JTP1240R TACT switch w/ LED Red			x
7E34000501	JTP1240G TACT switch w/ LED Green			x
7E34002911	EC12E2420803 12mm Rotary Encoder, Insulated shaft, Vertical			x
7E12201111	Potmeter, 10K0, 11mm, Linear			x
<b>Mainboard.</b>				
731014011	Blacksmith service Main PCBA, P18301 Leaded		x	x
7E48407911	512k x 8 Flash, Platinum1 W/Program			x
7E49006511	ATMEGA88-20AU Microcontroller boot(PL1H1 Platinum mainboard)			x
<b>Power Board</b>				
500011011	1000W Icepower amplifier 115/230VAC			x
<b>Chassis.</b>				
581099013	DR09081-D Front for Platinum 1146		x	x
575130013	DR09080-D, Window for Blacksmith		x	x
575160011	TCE logo for Cabinet grille		x	x
<b>Miscellaneous.</b>				
7E57506411	DR09011-C, Switchcap for 1038 Dirch Amp1		x	x
7E57506499	10 pack DR09011-C, Switchcap Rebelhead Dirch Amp1		x	x
7E57506511	DR09012-A, Switch Lightpipe for Dirch Amp1		x	x
7E33806413	DR09801-E, Plastic knob for Encoder - 1038 Dirch	x	x	x
7E33806513	DR09802-D, Plastic knob for Pots - 1038 Dirch	x	x	x
598500011	80x80x25mm MAGLev fan		x	x
575170011	Rubber foot F1692	x	x	x
562020070	M5x16mm Screw Torx BN20005, Black for Rubber foot	x	x	x