

| C300 | | | | |
|-----------------------|--|----------------------|----------|----------|
| Part number | Part name. | Service level | | |
| | | 1 | 2 | 3 |
| Front. | | | | |
| 7E33802001 | Button with white line 16,5mmØ DR03101-C | x | x | x |
| 7E33802011 | Button with white line 22,5mmØ DR03102-C | x | x | x |
| 7E33802041 | Push button 6,5mmØ DR03103-C | x | x | x |
| Mainboard. | | | | |
| 7F82010003 | PCBA, P20201, C300 Mainboard | | x | x |
| 7E48402811 | 256kX8 39VF020 C300 FLASH W/Program | | | x |
| 7E48100106 | 128kX8 HIGH SPEED SRAM SOJ32-400Mill | | | x |
| 7E49000101 | XCB56362PV100 DSP QFP144-3 | | | x |
| 7E49001401 | ATMEGA8L-8AU TQFP32 PENGUIN | | | x |
| 7E12200201 | 10K RP11A11VB2 POTENTIOMETER 20% | | | x |
| 7E34001001 | 16Pos DigRot. Switch BTDS20HS-116-F15-1 | | | x |
| 7E34001011 | Push Switch JTP1239 | | | x |
| 7E52200301 | S4-BBB-PCC STEREO JACK CONNECTOR | | | x |
| Chassis. | | | | |
| 7E33802051 | Grip, Black DR03106-E | x | x | x |
| Power supply | | | | |
| 7E50000111 | Switching power supply - Pinquin | | x | |
| Miscellaneous. | | | | |
| 7E60300201 | Foam For Penguin product without Logo | x | x | |