

Ditto Looper

tc electronic

| Part number | Part name. | Service level | | |
|-------------|---|---------------|---|---|
| | | 1 | 2 | 3 |
| 7E58209413 | DR06108-C, Footswitch TOP | X | X | X |
| 7E34004111 | Foot Switch Actuator, PB-4066C | | | X |
| 7E57605299 | 10 pcs DR06222 Rubber bottom for the mini serie | X | X | X |
| 7E57508811 | Erik DR06115-A, Pot-knob - BLACK | X | X | X |
| 7E12202701 | Erik Potentiometer linear 9mm | | | X |
| 7E50500511 | Relay, DPDT, latching, single coil | | | X |
| 7E52300011 | DC Power Connector | | | X |
| 7E34004211 | TACT Switch Lead 12mm | | | X |
| 7E56200211 | Screw, M3x8,0mm WN1552 EJOT PT TYP D6 | | X | X |