

Ditto x 2 Looper



Part number	Part name.	Service level		
		1	2	3
7E58209413	DR06108-C, Footswitch TOP Nut		X	X
7E34004111	Foot Switch Actuator, PB-4066C			X
7E57510713	DR06212-D, Plastic Knob, Black	X	X	X
7E34003811	Erik Toggle switch 3 positions		X	X
7E34005711	Toggle switch 3 positions momentary		X	X
7E12202701	Erik Potentiometer linear 9mm		X	X
7E50500511	Relay, DPDT, latching, single coil			X
7E52300011	DC Power Connector			X
7E34004211	TACT Switch Lead 12mm			X
7E57606112	DR06243-B, 1251, Hannibal, Left Rubber Feet, Black	X	X	X
7E57606212	DR06244-B, 1251, Hannibal, Right Rubber Feet, Black	X	X	X