

Service Note		
Product	Description:	Service note no.
M5000	Replacing the CPU PCB	712 10 T050

Service Note

M5000 Replacing the CPU PCB 712 10 0521

IMPORTANT:

Replacement of CPU PCB should only be carried out by authorized technicians.

Procedure:

1. Check if any licenses are installed in Menu Config, - if possible.
2. POWER OFF AND DISCONNECT POWER CORD.
3. Dismount the top and bottom lid.
4. Disconnect the cables to the CPU PCB.
5. Remove two screws on the solder side of the CPU PCB.
6. Remove the two jack nuts and remove the CPU PCB.
7. Mount the new CPU PCB. Reverse of 3, 4, 5, 6.
8. Power On. The unit will show "Serial information mismatch ..."
9. Press DO and write down the error code.
10. Send the error code and the serial number of the mainframe which has to be programmed into the CPU PCB to the service dept. in Denmark, preferably by e-mail to:
tech@tcelectronic.com
11. You will receive a new code back ASAP which you must enter.
12. Finally, install the license codes again - if any!