


How to install boot software. Main board version PC13001-x

1. Power the unit off.
2. Copy the boot software (.ins file) to a PCMCIA card with a M5000.
3. Set jumpers according to fig. 2 below.
4. Insert the PCMCIA card.
5. Power the unit on.
6. Wait. The boot will install automatically.
7. Power off.
8. Set jumpers according to fig. 1 below.

Main board version PC13001-x


JP3, JP4, JP5 & JP6 controls boot mode:

Boot from Flash
(normal mode)



power supply ->

Boot from PCMCIA
(only used at factory)



power supply->