

| Part number | Part name.   | Service level |   |   |
|-------------|--|---------------|---|---|
|             |  | 1             | 2 | 3 |
| 7E57610912  | MASH Foot SwitchActuator MKII                              |               |   | X |
| 7E12202701  | Potentiometer linear 9mm                                   |               | X | X |
| 7E12202901  | Potentiometer linear 9mm w/11 Detents                      |               | X | X |
| 7E34003811  | Toggle switch 3 positions                                  |               | X | X |
| 7E50500511  | Relay, DPDT, latching, single coil                         |               |   | X |
| 7E52300011  | DC Power Connector   |               |   | X |
| 7E54602611  | USB Cable, A plug to MINI B plug, 1,0m                     | X             | X | X |
| 7E56307211  | DR06104-A, Captive Screw                                   | X             | X | X |
| 7E57508811  | DR06115-A, Pot-knob for 1096 Erik - BLACK                  | X             | X | X |
| 7E57603299  | 4 pcs Rubber Foot, 8 mm x T1.5 mm, Clear Silicone 80 shore | X             | X | X |