

# Harmony Control Guitar



TC order no:	Part name.	Service level		
		1	2	3
<b>Front.</b>				
7E57504411	Light bar for HANS DR05116-C	x	x	x
7E57504711	DR05118-E, Lightpipe Array for HANS		x	x
7E57504611	Foot switch collar for HANS DR05117-C	x	x	x
7F84412001	PCBA, P22655, V3 HarmonyControl UI		x	x
7E49004211	ATmega88 AVR QFP32/P08 (HANS 4M+3C)			x
7E34001411	R13-85 Switch,			x
7E34001499	R13-85 Switch, 10 pcs. package			x
<b>Main.</b>				
7F84411001	PCBA, P22613, V3 HarmonyControl Main		x	x
7E48401324	Flash IC w/prog for Harmony Control Guitar			x
7E52300011	DC Power Connector			x
<b>Power supply.</b>				
960899002	PowerPlug 12V	x	x	x
E52304011	Mains plug Australia for TC PowerPlug PSU	x	x	x
<b>Chassis.</b>				
7E58103712	HANS Right end cap DR05020-B	x	x	x
7E58103612	HANS Left end cap DR05019-B	x	x	x
<b>Miscellaneous</b>				
795299998	MIDI s/w upload board			x