

Part number	Part name.	Service level		
		1	2	3
7E12202701	Potentiometer linear 9mm		X	X
7E34003811	Toggle switch 3 positions		X	X
7E34004111	Foot Switch Actuator, PB-4066C		X	X
7E34004211	TACT Switch Lead 12mm		X	X
7E50500511	Relay, DPDT, latching, single coil			X
7E52300011	DC Power Connector			X
7E54602611	USB Cable, A plug to MINI B plug, 1,0m	X	X	X
7E56307211	DR06104-A, Captive Screw	X	X	X
7E57508811	DR06115-A, Pot-knob for 1096 Erik - BLACK	X	X	X
7E57603211	Rubber Foot, 8 mm x T1.5 mm, Clear Silicone 80 shore	X	X	X
7E58209413	DR06108-C, Footswitch TOP Nut		X	X