

Part number	Part name.	Service level		
		1	2	3
Mainboard				
7F85911071	PCBA, P22632, Perform VG, Mainboard		X	X
7E48419011	16 Mbit SPI Flash - w program / Perform-VG			X
7E34001021	Pushbutton switch WPS-2FL-B		X	X
7E49103311	AK5357ETP-E2 - Advanced Multi-Bit Delta-Sigma ADC			X
7E49103511	AK4621EFP-E2 Audio Codec SSOP30			X
7E52203111	3 Pol XLR Male for PCB JY-5032A			X
7E52203211	3 Pol XLR Female for PCB JY-5033A			X
7E52203611	6,3mm_1/4" Stereo Jack, Right Angle, PCB Mount			X
7E52205111	6,3mm_1/4" Stacked Dual Stereo Jack			X
7E52300011	DC Power Connector		X	X
DSP Board				
7F85913071	PCBA, P22610, Perform VG, DSP-board		X	X
7E49004811	DSPB56724AG DSP QFP144/P05			X
UI				
7F85912071	PCBA, P22633, Perform VG, UI-board		X	X
7E12203911	Potentiometer Infinite Rotation linear 11mm 20%			X
7E59803111	Microphone 9.7 x 6.5mm			X
Power supply				
960899002	PSU base PowerPlug12V/1A Level VI	X	X	X
E52304011	Mains plug Australia for Honor PSU Level VI	X	X	X
Miscellaneous.				
7E33804511	DR05101-A, Plastic knob Ø30 VoiceLIVE	X	X	X
7E54602611	USB Cable, A plug to MINI B plug, 1,0m	X	X	X
7E57506613	DR05139-C, Switch Cap Guide for HANS		X	X
7E57515214	DR10068-D, Perform-V, Plastic Cap Mic Stand Clip		X	X
7E57521113	DR10070-E, , Perform VG, KeyPad		X	X
7E57605012	Rubber Foot, 12.3mm x T2.0 mm, Clear Silicone 80 shore A	X	X	X