

Part number	Part name.	Service level		
		1	2	3
7E57610912	MASH Foot Switch Actuator MKII			X
7E12202701	Potentiometer linear 9mm		X	X
7E12202901	Potentiometer linear 9mm w/11 Detents		X	X
7E12203001	Potentiometer linear 10k 0,05W 20%		X	X
7E34003711	Erik Toggle switch 2 positions		X	X
7E50500511	Relay, DPDT, latching, single coil			X
7E52300011	DC Power Connector			X
7E54602611	USB Cable, A plug to MINI B plug, 1,0m	X	X	X
7E56307211	DR06104-A, Captive Screw	X	X	X
7E57513311	DR10001-A Plastic Knob, Black	X	X	X
7E57603299	4 pcs Rubber Foot, 8 mm x T1.5 mm, Clear Silicone 80 shore	X	X	X