

# RC4

Part number	Part name.	Service level		
		1	2	3
<b>Mainboard.</b>				
7F82511003	PCBA, P18581, 1038, RebelControl, Mainboard		x	x
7E34001411	R13-85 Switch			x
7E34001499	10 pcs package. R13-85 Switch			x
7E58204512	DR05022-E, Footswitch TOP for AC/EC Front			x
7E57505411	DR05130-C, Footswitch Lightguide Ring for AC/EC	x		x
<b>Chassis.</b>				
7E59106712	DR09033-B, Window for RebelControl	x	x	x
<b>Miscellaneous.</b>				
7E54601511	MIDI Cable for 1038, Dirch -> Remote, 6 mtrs.	x	x	x
7E60207111	Giftbox for RebelControl	x	x	x
7E60302511	Inner Foam for RebelControl giftbox	x	x	x