

Part number	Part name.	Service level		
		1	2	3
7E58209413	DR06108-C, Footswitch TOP nut		X	X
7E56602699	Footswitch with metal space nut		X	X
7E57508811	DR06115-A, Pot-knob for 1096 Erik - BLACK	X	X	X
7E12202701	Potentiometer linear 9mm		X	X
7E12202801	Potentiometer Stereo Linear 9mm		X	X
7E12202901	Potentiometer linear 9mm w/11 Detents		X	X
7E34003711	Toggle switch 2 positions		X	X
7E52300011	DC Power Connector			X
7E57603299	4 pcs Rubber Foot, 8 x T1.5 mm, Clear Silicone 80 shore	X	X	X
7E54301311	Flexstrip Cable FSN12A7			X
7E54301511	Flexstrip Cable FSN12A11			X
7E54602611	USB Cable, A plug to MINI B plug, 1,0m	X	X	X
E56307211	DR06104-A, Captive Screw 1109 Bluefin	X	X	X