

## Spare Parts for Triple-C, Single Channel

Item no.	Description
<b>Front section</b>	
7B80321001	TRIPLE-C Single, Front PCB w/ display <b>Discontinued</b>
7B80322001	TRIPLE-C, Display <b>Discontinued</b>
7E58200501	Triple-C Single, Front Panel <b>Discontinued</b>
7E33800501	Power Button, DR-01113
7E34000201	POWER SWITCH, SW/SPPH43
7E33905111	Plastic knob, for INPUTLEVEL, THRESHOLD, RATIO, ATTACK, RELEASE, LO-BAND, HI-BAND, LEVEL
7E12200101	POTMETER, 10k, for INPUTLEVEL, THRESHOLD, RATIO, ATTACK, RELEASE
7E34000901	POTMETER, 10K, w/Center detent, LO-BAND, HI-BAND, LEVEL.
7E33801201	Dual Encoder Inner knob, for VALUE SET + ENTER, DR-01117-A
7E33801301	DR01118-B, Dual Encoder Outer knob
7E33801399	<b>10 pack</b> DR01118-B, Dual Encoder Outer knob
7E34000801	Inner ENCODER, for VALUE SET + ENTER with push switch
7E34000701	Outer ENCODER, for PARAMETER, ENC/SRGP10-1
7E33801401	Inner Button 4X4, DR-01115-A
7E33801501	Cap for Button 4X4, DR-01116-A
7E34000501	TACT switch w/ LED Green, JTP1240G
7E59700101	Flat Ribbon Cable With 2x10 Pin Connect.
7E56700201	Plastic Spacer, double, DR-01112
<b>Chassis</b>	
7E58100102	Bottom panel/chassis, DR-01009-3
7E58100301	Side Panel, DR-01002-6
<b>Main board</b>	
7B80110301	Triple-C Single, Complete main board ( <b>Discontinued</b> )
7E33000101	CRYSTAL 24.576MHz HC49U 30PPM
7E33000201	CRYSTAL 22.5792Mhz XTAL\HC49 30PPM
7E39900101	DG441 QUAD SPST ANALOG SWITCH, SO16
7E48000105	1MX16 DRAM SOJ-42
7E48100106	HIGH SPEED SRAM 128kx8 SOJ32
7E49000101	DSP XCB56362PV100 QFP144-3
7E49100301	24-BIT 96kHz CODEC AK4524VF SSOP28
7E49100601	DIGITAL AUDIO RECIEVER CS8414-CS SSOP28
7E52200301	STEREO JACK CONNECTOR S4-BBB-PCC
7E58200401	Washer, Plastic, for Jack, DR-01025
<b>Power Supply</b>	
7E50000101	Switching Power Supply Unit
<b>Miscellaneous</b>	
E54700202	Cable U.S.A. Black 3x18 AWG SVT 180 cm.
E54700102	Cable EU Europe Black 3x0.75mm H05VV-F 180 cm
547004011	Power cord for UK (240V)