

VoiceLive 2 Extreme

tc electronic

Part number	Part name.	Service level		
		1	2	3
Analog I/O				
7F85614003	PCBA, P22631, 1184, Ulrich, VL 2 Extreme Analog IO		X	X
7E49100713	AK4620BVF 24bit 192Khz Codec - VSOP			X
7E49102111	AK5359ETP 24bit 192Khz ADC - TSSOP-16			X
7E52200401	XLR NC3FA-H-2 - Female			X
7E52202001	Dual Jack Cliff - FCR1124N			X
7E52203111	3 Pol XLR Male for PCB JY-5032A			X
7E52203611	6,3mm_1/4" Stereo Jack, Right Angle, PCB Mount			X
7E52204611	STEREO JACK PCB MOUNT/3.5MM			X
7E39301011	2A Slow-Blow Fuse 63V-AC/DC 1206		X	X
7E52300011	DC Power Connector			X
7E35100501	FDC658P Mosfet Transistor			X
7E34001021	Pushbutton switch WPS-2FL-B			X
UI				
7F85612001	PCBA, P22660, 1089 - VoiceLive 2 UI		X	X
7E33601001	LCD Display 192X64 BLUE NEGATIVE		X	X
7E34000401	JTP1240R TACT switch w/ LED Red			X
7E34001611	PEC12-4220F-N0024 ENCODER			X
7E49004611	ATmega88 AVR QFP32/P08 (VoiceLive 2 Program I)			X
7E34001611	PEC12-4220F-N0024 ENCODER			X
Digital I/O				
7F85611003	PCBA, P22617, 1184, Ulrich, VL 2 Extreme Digital IO		X	X
7E48407811	4M x 8 flash, VoiceLive 2 Extreme			X
7E49004111	DSPB56720AG DSP QFP144/P05			X
7E49102911	TAS1020B USB DRIVER TQFP-48			X
Foot switch board				
F85613001	PCBA, P22661, 1089 - VoiceLive 2 Foot_SW		X	X
7E34001411	R13-85 Switch			X
7E34001499	R13-85 Switch, 10 pcs. package			x
Miscellaneous.				
7E57507011	DR05234-A, overmoulded LowProfile knob	X	X	X
7E57505411	DR05130-C, Footswitch Lightguide Ring for AC/EC	X	X	X
7E57505711	DR05131-B, Footswitch Nut AC/EC Front	X	X	X
7E58207399	DR05147-D 10 pack VoiceLive 2, FootSwitch Collar, Black	X	X	X
7E57504211	DR05114-C, Switchcap for HANS	X	X	X
7E57504311	DR05115-B, Switch Lightpipe for HANS	X	X	X
7E57506613	DR05139-C, Switch Cap Guide for HANS			
7E33804511	DR05101-A, Plastic knob Ø30 VoiceLIVE	X	X	X
7E57507111	KB-R02AD-PA , Switch Cap forPT series Switch	X	X	X
7E58207014	VoiceLive 2 DR05143-D, LH ENDCAP		X	X
7E58207114	VoiceLive 2 DR05144-D, RH ENDCAP		X	X
7E54701412	DR05036-B Display Cable, 1089 Nares			X
7E54701512	DR05037-B Footswitch A Cable, 1089 Nares			X
7E54701612	DR05038-B Footswitch B Cable, 1089 Nares			X
7E54701712	DR05039-B Control Board to DSP Cable, 1089 Nares			X
7E54701812	DR05040-B DSP to Analog Board Cable, 1089 Nares			X
7E54602111	USB 2.0 cable VL2	X	X	X
7E34003111	PT-S3PL-2 POWER SWITCH	X	X	X
7E57602512	DR05145-B, VoiceLive 2 Rubber Foot	X	X	X
7E58207213	DR05146-C, VoiceLive 2 HANDLE		X	X
Power supply.				
960899002	PowerPlug 12V	X	X	X
E52304011	Mains plug Australia for Honor PSU Level VI	X	X	X