



(C) Telegonics
Wizard II
 P13006-C

JUMPER SETTING :
 Please refer to : Service manual

BATTERY
 Exchange procedure :
 Refer to service manual

PCMCIA CONNECTOR
 A B C

FRONT CONNECTOR 34

24-BIT DA CONVERTER

24-BIT AD CONVERTER

PLL CIRCUIT

DSP

JTAG

MPU

SRAM

FLASH

MIDI out **MIDI thru** **MIDI in**

AES/EBU IN **EXT. SYNC IN**

S/PDIF IN/OUTPUT
 IN : upper
 OUT : lower

RELAY BYPASS

AD AMP

GAIN

+15V
 AGND
 -15V
 +5V
 +5V-SB
 BROWN
 +5V
 RED
 DGND
 M13
 BROWN

+15V
 ORANGE
 AGND
 BLUE
 -15V
 YELLOW

+15V
 ORANGE
 AGND
 BLUE
 -15V
 YELLOW

M11 A B C D E F G H I J K L M M12