

## Air Base-12 Spareparts.

TC order nr:	Part name.	Service level		
		1	2	3
<b>AIR Calibration Equipment</b>				
795299999	AIR Calibration Equipment			x
<b>Flash</b>				
795201010	Flash w/program for Air main			x
<b>Modules / PCB / Comp.</b>				
<b>795202009</b>	Service PSU for Mary power supply			x
<b>795202010</b>	Service MARY Amplifier - BOM #GAB			x
795202001	Service 2-way Slave Main PCB			x
795202002	Service 2-way Master Main PCB			x
795036020	Trafo for AirBase 25 -12/24 120/240V			x
501016011	PF0011/30/63 - (BULGIN) IEC Connector (Power inlet)			x
<b>Woofers / Tweeters.</b>				
795036012	87999 Woofer for AirBase 12.		x	x
<b>Chassis.</b>				
584056511	R6323-1 Backplate for AIR base 12.		x	x
<b>Miscellaneous.</b>				
795999751	Box + packing: AirBase 12.	x	x	x
544046011	LAN cable, Category 5, shielded, 6 meter	x	x	x
547003012	Cable EU Europe Black 3x0.75mm H05VV-F 180 cm	x	x	x
547007012	Cable Australia 3x0.75mm 250 cm	x	x	x
544045511	Cable 8pol PH JST, 150mm Black	x	x	x
795750011	Flexible flat cable, 600mm, 26pol	x	x	x