

VoiceTone Create



TC order no:	Part name.	Service level		
		1	2	3
Front.				
7E57504111	Overmolded knob for HANS DR05113-B	x	x	x
7E57504211	Switch cap for HANS DR05114-C	x	x	x
7E57504311	Switch light pipe for HANS DR05115-B	x	x	x
7E57504411	Light bar for HANS DR05116-C	x	x	x
7E34001411	R13-85 Switch			x
7E34001499	R13-85 Switch, 10 pcs. package			x
7E57504611	Foot switch collar for HANS DR05117-C	x	x	x
7F84212001	PCBA, P22651, VoiceTone Create (V1) UI Board		x	x
7E12201011	Potmeter, 2K0, 11mm, 10C taper			x
7E12201111	Potmeter, 10K0, 11mm, Linear			x
7E12201211	Potentiometer 11mm Center snap			x
7E49004211	ATmega88 AVR QFP32/P08 (HANS 4M+3C)			x
Main.				
7F84211001	PCBA, P22611, VoiceTone Create (V) Mainboard		x	x
7E48401322	Flash IC w/prog for VoiceTone Create			x
Power supply.				
960899002	PowerPlug 12V	x	x	x
E52304011	Mains plug Australia for Honor PSU Level VI	x	x	x
Miscellaneous				
7E54700801	Ribbon Cable for UI board			x
795299998	MIDI s/w upload board			x
Chassis.				
7E58103712	HANS Right end cap DR05020-B	x	x	x
7E58103612	HANS Left end cap DR05019-B	x	x	x