

VoiceTone Synth



7E57504111
Overmoulded knob for HANS
DR05113-B

7E57504211
Switch cap for HANS DR05114-C

7E57504311
Switch light pipe for HANS DR05115-B

7E57504411
Light bar for HANS
DR05116-C

7E58103611
HANS Left end cap
DR05019-B

7E34001411
R13-85 Switch
7E57504611
Foot switch collar for HANS
DR05117-C

7E58103711
HANS Right end cap
DR05020-B