

## Spare parts for VoiceLive

TCCode	Description
<b>Front section</b>	
7B81120002	Front PCB VoiceLive
7E12200101	10k 20% POT/RK09K113 POTENTIOMETER
7E33905011	Plasticknob
7E33804511	Plastic knob Ø30 VoiceLIVE DR-05101-a
7E33800602	DR-01104-1, Console For Button
7E33800699	10 pack DR01104-1, Console For Button
7E33902302	EDIT, Cap For Button With Led
7E33900902	STORE, Cap For Button With Led
7E34001411	R13-85 Switch
7E34001499	R13-85 Switch 10 pcs package
7E33600601	LCD Display MC1602C8-SYL (60mA,STN,Y/G)
7E49001501	Voice Live, MPU-ATMEGA8535L
7E34000101	SW/TACT2 IT-1102-T TACT SWITCH
7E34001311	Push Encoder ALPHA - RE111-41B1N-15F-20P
<b>Mainboard</b>	
7B80110031	BL, Main Board PCB-A VOICELIVE
7E52300011	DC Power Connector
7E48401701	512kx8 39VF040 VOICELIVE FLASH W/Prog
7E48000105	KM416V1000CJ-5 DRAM
7E48100106	128kx8 HIGH SPEED SRAM
<b>Chassis</b>	
7E33905711	Window DRS05100-a for VoiceLive
7E59802011	U Type Cabinet Handle - Black Steel
7E57600711	Rubber bottom
7E59700101	Ribbon Cable Front to main
7E56301611	M3x8 Hexalobular Black - (BN15857)
7E59801011	Mounting washer for handle-black steel
<b>Micamp</b>	
7B81123002	MIC AMP VoiceLive
<b>Power supply</b>	
7E50000101	Manhattan Power supply