

Fireworx Service-partlist

TCCode	Description	used pcs.
Front section		
720035011	Complete Front assembly	1
720052011	Encoder + nut, for PARAMETER, VALUE and Alpha MOD	3
589017011	Nut for encoder	3
338056111	Plastic knob for encoder	3
122800011	10KB D40Potmeter for IN or OUT	2
720015111	Complete set of FireworX Front boards, version PC12505-1 w/LCD (S/N must be stated)	1
336050011	LCD Display DMF50316 NFU-FW LCD	1
339000511	Black push button "BYPASS"	1
339002111	Grey push button "DELAY"	1
339002011	Grey push button "FILTERS"	1
339002211	Grey push button "REVERB"	1
339001811	Grey push button "PITCH"	1
339001911	Grey push button "CHORUS"	1
339000811	Black push button "RECALL"	1
339000911	Black push button "EFFECTS"	1
339001011	Black push button "I/O SETUP"	1
339001111	Black push button "STORE"	1
339001211	Black push button "MOD"	1
339001311	Black push button "UTILITY"	1
339002311	Grey push button "ENTER"	1
Chassis		
584003012	Top Lid for FireworX	1
586000011	Wing/side panel for FireworX	2
Mainboard		
720011131	Complete PLL board, version PC12903-3 (without sample rate converter chip)	1
720018311	Fast Ex. RAM board, version PC12902-3	1
342000011	Battery, Type:CR2032-FT-4-2	1
522027011	1/4 inch jack socket, for EXTERNAL CONTROL	1
522042011	RCA/Phono, double, female, for S/PDIF IN/OUT	1
Power Supply		
720060011	Complete power supply module	1
Miscellaneous		
720070511	1M PCMCIA card w/application software	
611012011	Empty 512K PCMCIA card for presets	
E54700202	Cable U.S.A. Black 3x18 AWG SVT 180 cm.	
E54700102	Cable EU Europe Black 3x0.75mm H05VV-F 180 cm	
547004011	Power cord for UK (240V)	