


QUINTET

Part number	Text
Front Section	
7E33600701	LCD Display MC16011A8-SYL (60mA, STN,)
7E33800402	Big Plastic knob Ø30 For Mnhatn DR-01102
7E34000301	ENCODER/EC12E24204 without push function
7E33800501	Power Button, DR-01113
7E33800602	DR01104-1, Console For Button
7E33801401	DR01115-C, Inner Button 4X4 - Clear
7E33801501	DR01116-A, Cap for Button 4X4
7E33900902	STORE, Cap For Button With LED
7E33902302	EDIT, Cap For Button With LED
7E33901102	RECALL, Cap For Button With LED
7E33901202	>, Cap For Button Without LED
7E33902502	BYPASS, Cap For Button With LED
7E33905111	Small Plastic knob 13mm for Manhattan
7E12200601	RK1112N-C1K,L-20P 1K0 20% LOG Potmeter Mic input
7E34000201	Power switch SW/SPPH43
	Regarding MPU, please see at the bottom
Main board	
7E47100201	INA163 Burr Brown Mic_Preamplifier V SO14
7E48000105	KM416V1000CJ-5 DRAM 1MX16 SOJ-42
7E48401501	Quintet, Flash W/Programme (Not available any more)
7E49000219	Quintet MPU, AT90LS8535-4JC
7E54300011	Cable for MicAmp Gain VoiceWorks/Quintet (Not available any more)
7E59700101	Flat Ribbon Cable With 2x10 Pin Connect.

Chassis	
7E58100102	Bottom Plate DR-01041-D
7E58100301	Side Plate, Diecasted Al DR-01002-6
Power supply	
7E50000101	Manhattan Power Supply Unit

Regarding programmed MPU there are two types of housing. Please refer to numbers and picture below

7E49000219	Quintet MPU, AT90LS8535-4JC W/program	Old PLCC type
7E49000229	Quintet ATMEGA8535L-8AU Microcontroller TQFP-44 W/program	NEW TQFP type



Please disregard printing on label