

# Spark Booster

**tc electronic**

Part number	Part name.	Service level		
		1	2	3
7E58209413	DR06108-C, Footswitch TOP nut		X	X
7E56307211	DR06104-A, Captive Screw	X	X	X
7E57508911	Erik DR06115-A, Pot-knob- RAL1013	X	X	X
7E12202701	Erik Potentiometer linear 9mm		X	X
7E12203201	Potentiometer linear 9mm 50k 0,05W 20% w/center detent		X	X
7E12203301	Potentiometer NLOG 9mm 100k 0,05W 20%		X	X
7E34003811	Erik Toggle switch 3 positions		X	X
7E57603299	4 pcs Rubber Foot, 8 x T1.5 mm, Clear Silicone 80 shore	X	X	X
7E52300011	DC Power Connector			X
7E54301311	Flexstrip Cable FSN12A7			X
7E54301511	Flexstrip Cable FSN12A11			X