PCMCIA-connector
FLASH
SRAM-odd
SRAM-even
OPTION
EEPROM
REMOTE port fuse
H8-3003
14.112MHz
PEDAL input
REMOTE port
RS-485
RESET
DGND
MIDI out
MIDI thru
MIDI in
Min. 3V
SMPTE in
11.28MHz
12.28MHz
24MHz
3V3
1V8
5V
BUS CONNECTOR
Floppy connector
Floppy POWER connector
JTAG
P05100-E
Exchange procedure : Refer to service manual
NORMAL SW1
Setting: ON ON OFF OFF OFF OFF ON ON
X-only
M5000-X connector
Please refer to service manual