M-ONE-XL

7E33800501
Power Button

7E58100301
Side Panel

7E33905111
Plastic knob,
for INPUT, MIX and EFFECT BAL



7E33800702
Inlet For Button Without Led

7E33800602
Console For Button

Cap for buttons:

7E33901202 ">", Cap For Button Without Led

7E33800402
Big Plastic knob Ø30

7E58100301
Side Panel



7E33800802
Inlet For Button With Led

7E33800602
Console For Button

Cap for buttons:

7E33900102 "ROUTING", Cap For Button With Led
7E33900202 "I/O", Cap For Button With Led
7E33900302 "TAP", Cap For Button With Led
7E33900402 "UTILITY", Cap For Button With Led
7E33900502 "ALGO|EDIT 1", Cap For Button With Led
7E33900602 "ALGO|EDIT 2", Cap For Button With Led
7E33900702 "BYPASS 1", Cap For Button With Led
7E33900802 "BYPASS 2", Cap For Button With Led
7E33900902 "STORE", Cap For Button With Led
7E33901102 "RECALL", Cap For Button With Led
7E33901002 "ENTER", Cap For Button With Led
7E33901402 "EXIT", Cap For Button Without Led

Edited by: FNN
Date: 12-04-2011