Pedal in

MIDI out

MIDI thru

MIDI in

JUMPER SETTING :
Please refer to : Service manual

NORMAL MODE

S/PDIF IN/OUTPUT
IN : upper
OUT : lower

AES/EBU IN

EXT. SYNC IN
OUT IN

JTAG

DSP

FLASH

SRAM

MPU

DGND

DGND

+5V

AGND

AGND

+15V

-15V

+5V

+5V-SB

+15V

-15V

+4.8V

RELAY BYPASS

AD AMP

GAIN

24-BIT DA CONVERTER

24-BIT AD CONVERTER

PLL CIRCUIT

FRONT CONNECTOR 34

PCMCIA CONNECTOR

BATTERY
Exchange procedure :
Refer to service manual

SB-VCC VIOLET
+5V-SB BROWN
+15V ORANGE
AGND
DGND BLACK
+5V RED
-15V YELLOW
BLUE

Wizard II
P13006-D