Service Note		
Product	Description:	Service note no.
TC1280	New value for the fuses F402 and F403	705 10 03 06

IMPORTANT:

Modification should only be carried out by skilled technicians. This note concerns units with serial no. lower than 121750

Symptoms before modification:

The fuses F402 and F403 on the main board blows without reason.

Procedure:

- 1. Turn Off Power And Disconnect Power Cord.
- 2. Dismount the top lid.
- 3. Replace F402 and F403 with new fuses. The value for new fuses must be 630 mAT/250 V.
- 4. Mount the top lid.
- 5. Connect power cord and turn on power.