

Instructions

Here is what is needed

- Rubber mat for workbench surface
- Cloth's for wiping down product
- Box cutter for opening boxes
- 4mm bit for drill
- #2 Philips bit for drill
- Magnetic hex bit holder for drill for the above bits
- Small electronic snips

Steps:

1. Carefully unbox Outer and inner cartons by cutting packing tape on bottom of cartons
2. Remove 402 from Carton and remove from white protective pouch carefully
3. Remove 10x Philips screws from around the outer edge of back panel
4. Using a 5mm bolt, screw this into one of the existing open holes – it will push off the back panel (there is a gasket between the panel and enclosure that makes it 'stick') –OR- use a chopstick/wooden object to carefully push the back panel out through the port.
5. Locate C62 capacitor (ref photographs below)
6. Carefully cut out the C62 capacitor and discard (ref photograph below)
7. Carefully insert the back panel/amp assembly back into the cabinet
8. Wipe the monitor down with a soft cloth to remove any dust/debris/fingerprints
9. Re-insert into its white protective pouch and re-apply tape.
10. Put monitor back into Styrofoam end-caps ensuring all accessories are included and re-seal inner box.
11. Insert inner box into outer sleeve ensuring cutout and serial # line up.

The following photographs are intended for reference, however, if you have any queries on the process, please contact craig.skinner@tannoy.co.uk or call on +44 (0) 1236 702571





